



Wemo Stage WSC010 User Guide

The **Wemo Stage Smart Scene Controller, WSC010** is a *Bluetooth®*-powered HomeKit® remote that provides a physical way to control the HomeKit Scenes. With the ability to be used as a remote or attached to the wall like a light switch with its magnetic faceplate, the Wemo WSC010 provides a convenient way to control your HomeKit devices without using the Apple® Home app.



About the Wemo WSC010

[Meet the Wemo Stage Smart Scene Controller, WSC010\(https://www.belkin.com/us/support-article?articleNum=318294\)](https://www.belkin.com/us/support-article?articleNum=318294)

[Wemo Stage WSC010 Frequently Asked Questions\(https://www.belkin.com/us/support-article?articleNum=318305\)](https://www.belkin.com/us/support-article?articleNum=318305)

[Light behavior of the Wemo Stage WSC010\(https://www.belkin.com/us/support-article?articleNum=318295\)](https://www.belkin.com/us/support-article?articleNum=318295)

[Apple HomeKit-supported Wemo products\(https://www.belkin.com/us/support-article?articleNum=306794\)](https://www.belkin.com/us/support-article?articleNum=306794)

Setup

[What is needed to set up the Wemo Stage WSC010\(https://www.belkin.com/us/support-article?articleNum=318297\)](https://www.belkin.com/us/support-article?articleNum=318297)

[Where to locate the HomeKit code for the Wemo Stage WSC010\(https://www.belkin.com/us/support-article?articleNum=318298\)](https://www.belkin.com/us/support-article?articleNum=318298)

[Installing and replacing the battery in the Wemo Stage WSC010\(https://www.belkin.com/us/support-article?articleNum=318299\)](https://www.belkin.com/us/support-article?articleNum=318299)

[How to add the Wemo Stage WSC010 to your Apple Home network\(https://www.belkin.com/us/support-article?articleNum=318307\)](https://www.belkin.com/us/support-article?articleNum=318307)

[How to wall mount the Wemo Stage WSC010\(https://www.belkin.com/us/support-article?articleNum=318308\)](https://www.belkin.com/us/support-article?articleNum=318308)

Using the Wemo WSC010 with the Apple Home Scene

[Meet the Apple Home app\(https://www.belkin.com/us/support-article?articleNum=275544\)](https://www.belkin.com/us/support-article?articleNum=275544)

[How to download the Apple Home app to your iOS device\(https://www.belkin.com/us/support-article?articleNum=317773\)](https://www.belkin.com/us/support-article?articleNum=317773)

[What is an Apple Home Scene\(https://www.belkin.com/us/support-article?articleNum=318300\)](https://www.belkin.com/us/support-article?articleNum=318300)

[How to assign Scenes to the Wemo Stage WSC010\(https://www.belkin.com/us/support-article?articleNum=318301\)](https://www.belkin.com/us/support-article?articleNum=318301)

[How to control scenes with your Wemo Stage WSC010\(https://www.belkin.com/us/support-article?articleNum=318302\)](https://www.belkin.com/us/support-article?articleNum=318302)

[How to create a Scene in your Apple Home app\(https://www.belkin.com/us/support-article?articleNum=318309\)](https://www.belkin.com/us/support-article?articleNum=318309)

Troubleshooting

[How to reboot your Wemo Stage WSC010\(https://www.belkin.com/us/support-article?articleNum=318303\)](https://www.belkin.com/us/support-article?articleNum=318303)

[How to factory restore your Wemo Stage WSC010\(https://www.belkin.com/us/support-article?articleNum=318304\)](https://www.belkin.com/us/support-article?articleNum=318304)

[How to update the firmware of the Wemo Stage WSC010\(https://www.belkin.com/us/support-article?articleNum=318347\)](https://www.belkin.com/us/support-article?articleNum=318347)

[How do I update the firmware on my HomeKit-only Wemo\(https://www.belkin.com/us/support-article?articleNum=317774\)](https://www.belkin.com/us/support-article?articleNum=317774)

[The Wemo I'm trying to set up doesn't appear in the Wemo app's list of devices\(https://www.belkin.com/us/support-article?articleNum=317772\)](https://www.belkin.com/us/support-article?articleNum=317772)

© 2022 Belkin International, Inc.