

Q

Wemo Stage WSC010 User Guide

The **Wemo Stage Smart Scene Controller, WSC010** is a *Bluetooth*®-powered HomeKit® remote that provides a physical way to control the HomeKit Scenes. With the ability to be used as a remote or attached to the wall like a light switch with its magnetic faceplate, the Wemo WSC010 provides a convenient way to control your HomeKit devices without using the Apple® Home app.



About the Wemo WSC010

<u>Meet the Wemo Stage Smart Scene Controller, WSC010(https://www.belkin.com/us/support-article?articleNum=318294)</u>

Wemo Stage WSC010 Frequently Asked Questions(https://www.belkin.com/us/support-article? articleNum=318305)

Light behavior of the Wemo Stage WSC010(https://www.belkin.com/us/support-article?articleNum=318295)

Apple HomeKit-supported Wemo products(https://www.belkin.com/us/support-article?articleNum=306794)

Setup

What is needed to set up the Wemo Stage WSC010(https://www.belkin.com/us/support-article? articleNum=318297)

Where to locate the HomeKit code for the Wemo Stage WSC010(https://www.belkin.com/us/support-article? articleNum=318298)

<u>Installing and replacing the battery in the Wemo Stage WSC010(https://www.belkin.com/us/support-article?articleNum=318299)</u>

How to add the Wemo Stage WSC010 to your Apple Home network(https://www.belkin.com/us/support-article?articleNum=318307)

How to wall mount the Wemo Stage WSC010(https://www.belkin.com/us/support-article?articleNum=318308)

Using the Wemo WSC010 with the Apple Home Scene

Meet the Apple Home app(https://www.belkin.com/us/support-article?articleNum=275544)

<u>How to download the Apple Home app to your iOS device(https://www.belkin.com/us/support-article?articleNum=317773)</u>

What is an Apple Home Scene(https://www.belkin.com/us/support-article?articleNum=318300)

How to assign Scenes to the Wemo Stage WSC010(https://www.belkin.com/us/support-article?articleNum=318301)

How to control scenes with your Wemo Stage WSC010(https://www.belkin.com/us/support-article?articleNum=318302)

How to create a Scene in your Apple Home app(https://www.belkin.com/us/support-article? articleNum=318309)

Troubleshooting

How to reboot your Wemo Stage WSC010(https://www.belkin.com/us/support-article?articleNum=318303)

How to factory restore your Wemo Stage WSC010(https://www.belkin.com/us/support-article?

articleNum=318304)

<u>How to update the firmware of the Wemo Stage WSC010(https://www.belkin.com/us/support-article?articleNum=318347)</u>

<u>How do I update the firmware on my HomeKit-only Wemo(https://www.belkin.com/us/support-article?articleNum=317774)</u>

The Wemo I'm trying to set up doesn't appear in the Wemo app's list of devices(https://www.belkin.com/us/support-article?articleNum=317772)

© 2022 Belkin International, Inc.