






STEP 11




STEP 12

Recommended Maximum Weight



\*Unit in Pound(lbs.)



**WARNING:**  
>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.  
>DO NOT allow children to climb on unit.  
> Put heavier items on lower shelves.



Assembly Instruction

Furinno Lucca Simple Design 4-Drawer Dresser

MODEL : 19155H




Customer Support

**NEED HELP?** For replacement requests or product inquiries, please contact our Customer Service Team by emailing us at [support@furinno.com](mailto:support@furinno.com). Thank you for selecting Furinno!













[www.furinno.com](http://www.furinno.com)
















## EXPLODED VIEW



## PARTS LIST

 LEFT PANEL   1 PC	 RIGHT PANEL   1 PC	 TOP PANEL   1 PC
 BOTTOM PANEL   1 PC	 BOTTOM BACK PANEL   1 PC	 DRAWER FRONT   4 PCS
 DRAWER SIDE   8 PCS	 DRAWER BOTTOM   4 PCS	 DRAWER BACK   4 PCS
 SUPPORT PANEL   1 PC	 KICK PANEL   1 PC	 UPPER BACK PANEL   1 PC


## HARDWARE LIST

 CAM BOLT   12 PCS	 CAM LOCK   12 PCS	 DOWEL   24 PCS
 FLAT HEAD SCREW   48 PCS	 PAN HEAD SCREW   46 PCS	 POWER PIN   18 PCS
 DRIVE FASTENER   16 PCS	 HANDLE SCREW   8 PCS	 L BRACKET   4 PCS
 DRAWER SLIDE   4 SETS	 DRAWER BRACKET   8 PCS	 WALL MOUNTING SET   1 SET
 HANDLE   4 PCS		


## USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.


## STEP 9




## STEP 10




STEP 7




STEP 8




STEP 1




STEP 2




## STEP 3




TOOL REQUIRED





## STEP 4




TOOL REQUIRED






## STEP 5




TOOL REQUIRED




## STEP 6



TOOL REQUIRED



TOOL REQUIRED



**WARNING**  
Please make sure that the Back Panel is attached securely. All nails must be driven into the parts straight and centered. Failure to do so could cause instability, product collapse, and/or serious injury.