

Galaxy A12  
SAMSUNG

AT&T



Let's get started



AT&T 5-Star  
Eco-Rating 2.0  
att.com/ecospace

WIRELESS  
EMERGENCY  
ALERTS  
CAPABLE



AT&T Eco Rating 2.0 only applies to Galaxy A12. For limited factors evaluated visit [att.com/EcoSpace](http://att.com/EcoSpace). Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

©2021 Samsung Electronics Co., Ltd. LTE is a trademark of ETSI. 4G LTE is not available everywhere. Wi-Fi is a trademark of the Wi-Fi Alliance. Contains Lithium-ion battery - recycle or dispose of properly. Portions © 2021 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners. Images shown are for reference only.




GH68-53205A

Printed in USA

## Optimize the battery

From the home screen, swipe up for **Apps**, and then tap **Settings** > **Device care** .



## What's in the box

- Samsung Galaxy A12
- SIM card
- SIM Ejector Pin
- Fast Charging Wall Charger
- USB-C Cable
- Let's get started guide
- Terms and Conditions

## Useful apps\*



### myAT&T

Manage your account, track your usage, review and pay your bill, and update your data plan service.



### AT&T ProTech

Have a question, call or chat with a live AT&T ProTech support expert.



### AT&T Smart Wi-Fi

Find and auto-connect to available hotspots.



### Device Help

Get easy to understand solutions & device-troubleshooting help



### HBO Max

Stream the HBO you love, together with more great TV and movies, plus new Max Originals you can't wait to see.

\*Compatible device and subscription may be required. Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, go to <https://att.com/shop/apps>.

## Find more information

### Manage your account with myAT&T

- On your phone: Swipe up for **Apps**, and then tap the **AT&T** folder > **myAT&T**.
- On the web: [att.com/myATT](http://att.com/myATT)

Compatible device and online account required. Data and messaging rates may apply for download and app usage.

### Need more help?

- On your phone: Swipe up for **Apps**, and then tap **AT&T** folder > **Device Help**.
- On the web: [att.com/DeviceHowTo](http://att.com/DeviceHowTo)

### Give us a call

- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878


### Device Protection

Remember to protect your device against loss, theft and damage. Learn more at [att.com/protectyourdevice](http://att.com/protectyourdevice).

### Samsung Care

- To access user manuals, tips, videos, and more, visit [samsung.com/us/support](http://samsung.com/us/support).
- For hardware or software support, call 800.726.7864 or visit [samsung.com/us/support/contact](http://samsung.com/us/support/contact).
- To find a repair center, visit [support-us.samsung.com/cyber/locator/asc\\_locator.jsp](http://support-us.samsung.com/cyber/locator/asc_locator.jsp).

## Your new phone



Need more help?


Swipe up for **Apps** > **AT&T** folder > **Device Help**

Rear cover and battery are not removable.  
Do not attempt to remove.

## Easily adjust settings

### Settings menu

From the home screen, swipe up for **Apps**, and then tap **Settings**.



### Quick settings

Drag the Status bar down to display the Notification panel.

In addition to notifications, the Notification panel also provides quick access to device functions such as Settings, Search and Wi-Fi.



## Capture life's moments

### Take a picture

From the home screen, tap **Camera** > **PHOTO**.

- Pinch the display to zoom in or out.
- Tap to take a photo.
- Tap to take selfies.
- Swipe left and select **MORE** for shooting modes.

### Record a video

From the home screen, tap **Camera** > **VIDEO**.

- Tap to start recording.
- Tap to capture a picture while recording.
- Tap to pause recording.
- Tap to end recording.

### Share a picture or video

1. After taking the picture, tap the image viewer at the bottom left of the screen.
2. Select the photo you want to share and then tap **Share**.
3. Select the desired option to share your photo and follow the prompts.

## How to replace the SIM

### Remove SIM/microSD tray

- Use the tool to open the SIM/microSD™ card tray.

### Insert SIM/microSD card

- Place the SIM card and optional microSD card (sold separately) into the tray with the gold contacts facing down.

### Turn on your new phone

- Press and hold the **Side** key until the device turns on.



## Call family & friends

### Make a call

1. From the home screen, tap **Phone**.
2. Place a call using one of the following:
  - **Keypad:** Displays the keypad, and enter a phone number.
  - **Recents:** Select from call history.
  - **Contacts:** Select from address book.
3. Tap to make a voice call or to make a video call.



### Check Voicemail

1. From the home screen, tap **Phone**.
2. Tap **Voicemail**.

### Visual Voicemail

1. From the home screen, swipe up for **Apps**, and then tap **Visual Voicemail**.
2. Select a message to play.

## Surf & stream in no time

### Connect to Wi-Fi

1. From the home screen, swipe up for **Apps**, and then tap **Settings** > **Connections** > **Wi-Fi**.
2. Tap the Wi-Fi slider to turn it on.
3. Tap a network, enter a password if required, then tap **Connect**.



### Use Bluetooth

1. From the home screen, swipe up for **Apps**, and then tap **Settings** > **Connections** > **Bluetooth**.
2. Tap the Bluetooth slider to turn it on.
3. Tap the field next to your device name to make it visible for pairing.
4. Tap a device from the list to initiate pairing.

