

US UK Dear user Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully. 1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. 2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty. 1	Selection of working mode and charging indication Selection of working mode and charging indication 1. Wired USB mode: In keyboard mode, turn the toggle switch to the OFF position, connect the attached TYPE-C USB cable to the valid USB ports of the keyboard and the computer,the keyboard will charge while working. The "H" LED on the keyboard will be normally on in red, and after it is fully charged, it will change to be normally on in white. 2. 2.4G mode: In keyboard mode, turn the toggle switch to the 2.4G position, the "H" LED on the keyboard will slowly flash green. Insert the receiver into a valid USB port on the computer, and the "H" LED on the keyboard will be normally on in green (indicating that the keyboard is now successfully reconnected to the receiver and is in 2.4G working mode). If the keyboard needs to pair with the receiver, press and hold the FN+"4" key for about 3 seconds, and the "H" LED on the keyboard will flash green quickly. If the receiver on the USB port is reinserted or replaced, and pairing is successful, the "H" LED on the keyboard will be normally on in green. If the attached TYPE-C USB cable is connected to the keyboard and charging adapter (or a valid USB port on the computer) at this time, the keyboard will work in a 2.4G state while charging, and the "H" LED on the keyboard will be normally on in red, and when it is fully charged, it will change to be normally on in green. 3. Bluetooth mode: In keyboard mode, turn the toggle switch to the BT position. ① Hold the "FN+1/2/3" key on the keyboard for about 3 seconds, and the keyboard will enter the pairing mode of Bluetooth channel 1/Bluetooth channel 2/Bluetooth channel 3. The "H" LED on the keyboard will flash rapidly in blue/cyan/purple, and the keyboard will broadcast externally simultaneously: BT3. 0 KEYBOARD and BT5. 0 KEYBOARD devices. Depending on the terminal device that needs to be paired, follow the corresponding steps to pair with the keyboard. When pairing is successful, the "H" LED on the keyboard will be normally on in blue/cyan/purple (indicating that the keyboard is currently working in Bluetooth mode). If the attached TYPE-C USB cable is now connected to the keyboard and charging adapter (or a valid USB port on the computer), the keyboard will work in Bluetooth mode while charging, and the "H" LED on the keyboard will be normally on in red. When it 2	is fully charged, it will change to be normally on in blue/cyan/purple. ② When switching between the three paired Bluetooth channels is required, just press the FN+1/2/3 key to switch between them. 4. In power-off and charging mode - Turn the left toggle switch to the OFF position. When the computer is not connected via USB, the keyboard will be in the power-off mode. If the attached TYPE-C USB cable is connected to the keyboard and charging adapter, the keyboard will be in charging mode. Switching of backlight effect and customization ① Use FN+"INS"to switch between 12 (in a loop) backlight effects ② Use FN+"DEL"to switch between backlight colors ③ Use FN+"PRTSC" to customize the backlight effect. (1). The LED under the default W/A/S/D/ESC/4 direction keys is red. (2). In the current mode, press FN+"PRTSC", the CAPS indicator light will flash. Press continuously the key to be defined to select the color that needs to be lit normally (the LED under the corresponding key position will be normally lit in red → green → blue → yellow → purple → cyan → white → off in turn). (3). When the light color under the desired key position is set, press FN+"PRTSC" to save, and the backlight effect will run in the currently customized mode. If necessary, Redefine the backlight color of the corresponding key position and perform the second and third steps again. (4). To exit the current backlight effect customization mode, please press FN+"INS". ④ Side light effect switching (in a loop) FN+"PAUSE", flowing light - neon - normally red - normally orange - normally yellow - normally green - normally cyan - normally blue - normally purple - colorful breathing - OFF Low battery indication/charging/working current/power query ① Low battery indication: When the keyboard is in 2.4G or BT working mode, if the built-in battery of the keyboard is low, the "H" LED will flash slowly in red to remind 4	you to charge in time. ② Charging: This keyboard supports the charging mode of mobile power supply/external power adapter/valid USB port on the computer. For instructions on the charging status, please refer to the description in step 1 "Selection of working modes and charging indication" Warning: 1. Please use an external power adapter with an output of 5V±2A or 5V±1A; 2. Use a mobile power supply with an output of 5V±2A or 5V±1A. Use of mobile power sources/external power adapters outside the above range may cause certain secondary disasters or damage to the keyboard body! It is suggested to use a valid USB port on the computer for charging 3. Working current: (1). Wired USB state (battery being fully charged)<280mA, (2). Wired USB state (charging of battery)<780mA, (3). Working in 2.4G or Bluetooth mode,<280mA 4. Power query: Hold FN+"ENG" to turn off the current backlight effect: 1). When the battery is low, the LED under the number 1/2/3 will light up and display in red. 2). When the battery is not low, the LED under the number 1/2/3.../9/0 will display in green according to the current battery level. Note: This power indication is for reference only and is not for precise indication. Automatic hibernation/wake-up/manual power-off functions ① When the keyboard is in 2.4G or BT working mode, if it is not used for about 3 minutes, it will enter a power-saving state (turn off backlight and indicator lights). ② In any power-saving state, press any key to wake up the keyboard and use it again. ③ If you carry the keyboard out or do not use it for a long time, please turn the power switch at the bottom of the keyboard to the OFF position. 4	Functional description of other keys 1). When the bottom system switch is turned to WIN (the following key function categories apply to the WIN system) ①. The "FN+WIN" key can lock and unlock the WIN key and Menu key  to prevent accidental triggering of these two keys during gaming ②. FN+F1= Decrease screen brightness FN+F2= Increase screen brightness FN+F3= Display multi-task window(Alt+Tab) FN+F4= Desktop (Win+D) FN+F5= Return FN+F6= Search FN+F7= Previous title FN+F8= Play/pause FN+F9= Next title FN+F10= Mute FN+F11= Decrease volume FN+F12= Increase volume 2). When the bottom system switch is turned to MAC (the following key function categories apply to the MAC system), F1= Decrease screen brightness/FN+F1= F1 F2= Increase screen brightness/FN+F2= F2 F3= Display multi-task window/FN+F3= F3 F4= Call out Siri /FN+F4= F4 F5= app exposé function/FN+F5= F5 F6= Search/FN+F6= F6 F7= Previous title/FN+F7= F7 F8= Pause/FN+F8= F8 F9= Next title/FN+F9= F9 F10= Mute/FN+F10= F10
--	--	---	--	---

5