Manual

Model:STC01



電池警語:

此裝置使用內置的,不可拆制的可充雷鋰雷池。

■請勿拆解、打孔或損壞本裝置。

■請勿取出或嘗試取出使用者不可自行更換的內部雷池。

若未遵照下列準則則裝置內的鋰離子電池壽命可能會縮短或發生火災

■請勿將本裝置曝露於火焰、爆炸或其他危險中。

Battery Warning: This device uses a built-in, non-removable rechargeable

Failure to follow the guidelines below may shorten the lifespan of the lithium-ion battery inside the device or cause a fire!

- Do not disassemble, puncture, or damage this device.
- Do not remove or attempt to remove the internal battery that is not user-replaceable
- Do not expose this device to flames, explosions, or other hazards

1. 設備開機 長按設備按鍵5秒,設備響開機。

2. 綁定設備

■打開蘋果白帶的"杏找"ann。

將設備靠近您的iPhone,輕點"物品"標籤,選擇"添加新物品 ■點擊 "其他支持的物品" 點擊帶有" SXXXXX" 字樣的設備,輕點"連接"

- ■填寫"自定名稱"以命名您的設備并撰取一個表情符號。 ■同意將設備註冊到您的Apple II
- ■輕點"完成"綁定成功。

3. 啟用"丟失模式"

■ 打開蘋果自帶的"查找"app、點擊屏幕底部的"物品",然後點擊物品 的名稱。在"丟失模式"下方,點擊"啟用"

■點擊 "下一步" 核對信息後,請再次點擊 "啟用"完成設置。

■打開蘋果白帶的"查找"app、點擊屏墓底部的"物品",然後點擊物品的名稱

■ 在列表的最下方找到"移除物品",輕點"移除"完成操作。

說明·刪除設備後,設備會發出提示音,指示燈會閃爍6次,設備不會關機 處於配對模式。如果10分鐘之內,沒有重新配對,設備就會離開配對狀態 此時設備與app無法配對。如果需要配對設備,需要點擊設備按鍵一次 設備響、燈閃一次。此時設備進入配對狀態、可以跟app重新配對。

5. 設備充電說明

- A:無線充電 ■ 將卡片式防丟器放置在支援Oi標準的無線充電板 ト
- ■確保卡片式防丟器的充雷面(圖1)與充雷板對齊,

■按昭屈募指示操作,點擊"繼續"輸入聯絡雷話或者郵箱

- 紅色充電指示燈亮起表示正在充電
- 充滿電後,指示燈會變為綠色。

- complete the setup. Press and hold the button for 5 seconds, the device will beep and turn or
- 2. Pair the device
- Hold the device close to your iPhone, tap the Items tab, tap + and then Add
- Type a name for your device, select an emoil.
- 3. Enable Lost Mode

- 4 Remove the device

- Confirm the information, customize the lost message, and tap Activate to

- Under Lost Mode, tap Enable.

B: Magnetic charging (limited to products with magnetic touch spot) Read the instructions, tap Continue and enter a phone number or email

- Open the Find My app, tap the Items tab, then tap your item.
- Tap Remove Item and then tap Remove to complete the operation.
- 5. Charging method
- Tap Agree to acknowledge that this item will be linked to your Apple ID
 - with the charging device. The red charging indicator light is on, which means
 - When fully charged, the indicator light will turn green.

設備按鍵使用說明

1. 設備開機 ■將卡片式防丟器的充雷觸點與充雷線連接,正確連接時,磁吸將自動吸附 ■ 連接充電線至帶USB-A介面的電源滴配器*,紅色充電指示燈亮起表示正在充電。

2. 設備狀態確認

長按按鍵五秒、設備響、燈閃三次、設備開機。

充滿雷後,指示燈會變為綠色。 *注意: 必須使用輸出雷壓為5V的雷源滴配器:

磁吸觸點充雷(僅限於附帶磁吸觸點充雷的產品

■使用隨附的磁吸充雷線充雷。



首先,在Find My app中,移除設備。然後在設備開機後,雙擊設備按鍵,設備響 馬 上按住設備按鍵約六秒,直到設備發出提示音,指示燈閃爍三下,鬆開按鈕。 恢復出廠設置完成。設備就可以跟新的賬戶配對。

雙擊設備按鍵兩次,設備響,燈閃三次,說明設備在丁作。 設備在開機狀態下,2秒內連續按按鍵5次,設備發出提示音,指示燈閃爍三3 如果設備不響,說明設備處於關機狀態。長按按鍵五秒,開機。

刪除設備後,設備會發出提示音,指示燈會閃爍6次,設備不會關機,處於配對 模式。如果10分鐘內,沒有重新配對,設備就會離開配對狀態,此時設備與ann 加何確認設備是否已開啟? 無法配對。如果需要配對設備,需點擊設備按鍵一次,設備響,燈閃一次。 此時設備進入配對狀態,可以跟app重新配對。

4 恢復出廠設置

設備進入閣機狀態。

■雙擊設備按鈕、設備將發出蜂鳴聲、並且指示燈會閃爍三次、表示設備正在工作。 如果設備沒有響聲,說明設備處於關閉狀態。長按按鈕五秒鐘即可開啟設備

NFC標籤功能設置 (僅限於附帶NFC標籤功能的產品)

- 1. 確保手機支援NFC功能, 並在手機設置中開啟NFC 2. 打開NFC Tool App,進入 "NFC設置" 頁面。
- 3. 根據提示設置NFC功能,例如:
- 連絡人電話。 ■ 分享雷子名片。
- 4. 設置完成後,將手機靠折卡片式防丟器防丟器的NFC區域(圖1) 即可觸發相應功能

提供合理的保護,防止住宅安裝中的有害干擾。該設備會產生,使用並輻射射頻

能量,如果不按照說明安裝和使用可能會對無線雷涌信造成有害干擾,但是,

- 1 本設備符合FCC規則第15部分的規定 操作須滿足以下兩個條件 (1) 本設備不得浩成有害干擾
- (2) 太設備必須接受任何接收到的干擾 句括可能遵致音外操作的干擾 未經合規
- 負責方明確批准的任何更改或修改都可能導致使用者操作設備的許可權無效。 2. 本設備經過測試,符合FCC規則第15部分對B類數位設備的限制。這些限制旨在 -- 將設備連接到與接收器不同迴路的插座上
 - 4 該設備已經過評估可滿足一般射頻暴露要求
 - 5. 該設備可以在可攜式暴露條件下使用, 不受限制,

確定。鼓勵使用者嘗試涌過以下一種或多種措施來糾正干擾。

3 如果該設備確實對無線雷或雷視接收造成有害干擾可以通過關閉和打開設備來

FCC ID : 2BFM5-STC01

FCC ID: 2BEM5-STC01

如有問題,請聯絡客服:admin@singsun.com.hk

3. If this device does indeed cause harmful interference to radio or television reception.

following two conditions:

- Share the electronic business card.
- Double-click the device button, the device will been, and the light will flash three times, indicating that the device is working. If the device does not ring

NFC Tag Function Settings

(Only the product with NFC tag function)

- 1. Ensure that your mobile phone supports the NFC function and enable NFC in the phone settings.
- 2. Open the NFC Tool App and go to the "NFC Settings" page.
- 3. Set the NFC function according to the prompts, for example:
- 4 Set the contact phone number
 - After the settings are completed, bring your mobile phone close to the NFC area (as the pricutre) of the card tracker to trigger the corresponding function.

Notice

- to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna.
- 2) Increase the separation between the equipment and receiver.
- (3) Connect the equipment into an outlet on a circuit different from that to which the cause undesired operation.
 - (4) Consult the dealer or an experienced radio/TV technician for help.

 - . This device has been evaluated and found to meet general RF exposure requirement
 - 5. This device may be used under portable exposure conditions without restriction.

which can be determined by turning the device on and off, users are encouraged to t

near the button flashes. Do not release it. Continue to press and hold the button until the device emits a musi or the second time, and the indicator light flashes. Releasethe butto

4. Pair the device with the Find App again.

please contact: admin@singsun.com.hk

Quick instructions

1. Turn on the device

- Open the Find My app.
- Other Item.
- Open the Find My app, tap the Items tab, then tap your item.

Use the included magnetic charging cable to charge.

- Connect the charging spot of the card tracker to the charging cable magnetic head. When connected correctly, the magnetic suction will automatically

- Tap Connect SXXXXX.

A: Wireless charging Place the card tracker on a wireless charging device that supports QI

- Make sure the charging side (as the picture 1) of the card tracker is aligned
- voltage of 5V is required

will turn areen.

Connect the charging cable to the


adapter The red charging indicator

When fully charged, the indicator light

*Note: A power adapter with an output

turns on means the device is charging.

USB-A interface of the power



Long press the button for five seconds, the device will beep, the light will flash

Instructions for device button

2 Device status confirmation

Double-click the device button, the device will beep, and the light will flash three times, indicating that the device is working. If the device does not ring. the device is off. Long press the button for five seconds to turn it on.

six times, it will not shut down and will be in the pairing mode. If there is no the pairing state and can be paired with the app again.

First remove the item from Find My app, then, after the device is powered on double-click the device button. The device will been. Long press the device

three times, and the device will be turned on

device will beep, the light will flash three times, the device will be powered of

3. The device enters the pairing state again

re-pairing within 10 minutes, the device will leave the pairing state. If you want to pair a device at this time, you need to click the device button once. the device will been, and the light will flash once. At this time, the device enters

4 Factory Reset

button for six seconds until the device beeps and the light flashes three times Release the button to complete factory reset. The device can now be paired.

When the device is on press the device button 5 times in 2 seconds. The

How to confirm whether the device has been turned on?

• the device is off. Long press the button for five seconds to turn it on.

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the
- (1) This device may not cause harmful interference.

occur in a particular installation.

不能保證特定安裝中不會發生干擾.

- (2) This device must accept any interference received, including interference that may
- receiver is connected. Any changes or modifications not expressly approved by the party responsible for
- compliance could void the user's authority to operate the equipment. This device has been tested and complies with the limits for a Class B digital device.
- pursuant to Part 15 of the FCC Rules. These limits are designed to provide
- reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not

Any problem or suggestion.

- 重新調整或擺放接收天線 - 增加設備和接收器之間的距離。
- -- 請諮詢經銷商或經驗豐富的廣播/雷視技術人員尋求説明
 - 音樂提示音,按鍵附折指示燈閃燈,鬆開按鍵)
 - 3.重新開機蘋果裝置(如iPhone.iPad) 4.與查找app重新配對。

1. 更換手機網絡,如:WIFI和手機4G網絡之間切換

重要提示

2 對設備恢復出廠設置:在設備開機后,雙擊設備按鍵,設備變,馬上長按設備

恢復出廠設置完成。(注釋:長按設備按鍵2秒后,設備會有"嗶、嗶、嗶"

聲音,按鍵附折指示燈閃爍,不要鬆開,繼續按住按鍵,直到設備第一次發出

設備與查找app配對時,需要連接蘋果服務器,如出現無法配對的情況。

按鍵約8秒,直到設備第一次發出提示音,指示燈閃爍,鬆開按鍵。

一般是您使用的網絡暫時無法連接蘋果服務器,建議如下操作

Important Tips When pairing a device with Findmy app, the phone will link to the Apple server

1. Change the phone's network, such as switching between WiFi and mobile

Pairing may fail because of network problems. The following actions are

2 Factory Reset for the device:

When the device is powered on, double-click the device button. The device will beep then immediately long press the device button for eight seconds until the device beeps for the second time and the indicator light flashes.

Releasethe button, Factory Reset is completed. After long pressing the device button for 2 seconds the device will sound "tick tick, tick," and the indicator light

3. Restart the Apple device (such as iPhone or iPad)