

Cleaning

1. Shake off any sands or small particles in the poles and on the tent.
2. Wash the tent on a cold, gentle water. Or wash with a mild bleach-free detergent in cold to lukewarm water. Support hand washing and machine washing.
3. Hang it up outside to air dry.

Maintenance

1. Keep away from moisture and direct sunlight. Please store the product in a dry place.
2. There may be slight discoloration in the first few washings. Please wash separately from other clothes.

Warm Tips

1. Do not iron or tumble dry.
2. Do not use bleach and strong alkaline detergents.

! Cautions

1. Do not use this Beach Tent as a permanent shelter.
2. Do not set up this Beach Tent on steep inclines.
3. Do not set up this Beach Tent in heavy rain, storm, strong wind and lightning storms.
4. Never place any flame source in or near your tent. Never use, or light or refuel a heat source inside your tent.
5. Please use sunblock due to our product not being fully effective at preventing sunburn.
6. If you have any questions, please feel free to contact us.



E-mail: cs@raynesys.com

Made in China



Raynesys Beach Tent

User Manual



Square-top
Design



Wind-proof



Sun Safe
UPF 50+



Water
Resistance

Important Notice

Dear customer:

If you receive a product with missing or damaged parts, or if you have any questions about the product, please contact Raynesys customer service mailbox for feedback, and we will give you a satisfactory solution. We are very sorry for the possible inconvenience, and thank you for your understanding and support.

Raynesys wishes you enjoy it and have a happy life.


Contact us on Amazon: From your Amazon order details page, select **"Order" >>"Sold by" >>"Contact seller"**.




Package Contents



Beach Tent
x 1



8.5mm Thickened Fiberglass Poles
x 2



Sandbags
x 4



Steel Ground Pegs
x 6




Plastic Ground Pegs
x 6




Windproof Ropes
x 4




Accessory Bag
x 1




Storage Bag
x 1




① Choose an empty place, then take out the tent and lay it out.




② Connect 2 fiberglass poles.




③ Pass 2 poles through the pole sleeves and make both ends crossed.




④ Insert the crossed poles into the 4 corners.




⑤ Tie the poles tightly with a rope and hang the hooks.



⑥ Insert the ground pegs and tie the windproof ropes if necessary.



⑦ Fill 4 sandbags with sand.



⑧ Complete the installation.