




CAR MULTIMEDIA **COSTA MESA 900**




Enjoy it.

Operating instructions

The flagship product of the 'Symphony Series', Costa Mesa 900 features a brilliant 6.75-inch capacitive display with a high-end tuner and runs on Android OS Version 6.0



1. In any state, press this button to power on/off the device / light touch to mute audio output
2. Press this button to return to the previous page. Under any interface, tap the icon [↶] to return to the previous page.
3. Press this button to increase audio volume
4. Press this button to decrease audio volume
5. Press this button to go to home menu
6. Touch & slide the top row of the icons to the left or right to show more pages / icons.
7. Micro SD card slot for Navigation



- ① **SRC** button
Select source
- ② ▲ button
Eject a DVD/CD
- ③ **INFO** button
Show information on the display
- ④ **MENU** button
Call up DVD menu
- ⑤ **ZOOM** button
Zoom in on image area
- ⑥ **PIC** button
Adjust the display brightness
- ⑦ ⏮ button
Slow-motion playback
- ⑧ ■ button
Quit playback
- ⑨ 📶 **BAND** button
Select waveband/memory bank
- ⑩ 🏠 button
Call up main menu

- ⑪ ▶⏮ button
Start and interrupt playback
- ⑫ ⚙ button
Call up settings menu
- ⑬ ⏮/⏭/⏮/⏭ button
Navigate in menus and change settings
Starting station seek tuning (⏮/⏭)
Calling stored stations (⏮/⏭)
- ⑭ 📞 button
Answer a call
- ⑮ 📞 button
End/reject a phone call
- ⑯ **PHOTO** button
Call up folder overview of images
- ⑰ **MUSIC** button
Call up folder overview of audio files
- ⑱ Number buttons **0 - 9**
- ⑲ 🔄 button
Random track play / Shuffle
- ⑳ 🔄 button
Repeat function
- ㉑ 🔍 button
Scan function
- ㉒ **VIDEO** button
Call up folder overview of movies
- ㉓ 🔊 + / 🔊 - button
Adjust volume
- ㉔ **OK** button
Confirm selection
- ㉕ 🔇 button
Mute audio source
- ㉖ ⏮/⏭ button
Short press: Tune into stations manually; select title, chapter, movie
Long press: Fast Search
- ㉗ 📊 button
Equalizer
- ㉘ ✖ button
Delete last character of an entry
- ㉙ ⏮-A-B button
Define range for repeat function
- ㉚ **GOTO** button
Calling up direct input for FM transmitter track, chapter, movie or playtime
- ㉛ **ANGLE** button
Select camera viewing angle (if available on DVD)
- ㉜ **SUBTITLE** button
Select subtitle language (if available on DVD)
- ㉝ **AUDIO** button
Select playback language (if available on DVD)
- ㉞ ⏻ button
Switching device on/off

Contents

Safety notes	05	USB Music Function	15
Symbols used	05	Audio from USB	16
General Warning	05	Video from USB	16
Road safety	05	Features	17
Instructions to read this User Manual	06	PhoneLink	17
Declaration of conformity	06	Phone debugging	18
Cleaning the unit	06	Play store	19
Disposal notes	06	Browsing the internet	20
Warning	06	Video	20
Scope of delivery	06	Pictures	20
Placing the device in operation	07	SWC	20
Instructions to the panel buttons	07	File explorer	21
Switching on/off with the touch	07	Clock	21
Switch on/off via vehicle Ignition	07	Live wall papers	22
Main menu	07	Wall papers	22
Volume	07	Aux-In	22
Main interface	07	Blackout	22
Radio Function	09	Device Settings	23
Radio function operation	09	WiFi Settings	23
Setting the reception area	09	Portable WiFi Hotspot Settings	23
Tuning Into a station	09	Storage info	23
Storing stations manually	09	Apps	24
Scanning stations	10	Adding an account	24
Band Switch	10	Language input settings	24
Tune and Seek	10	Date & time settings	24
Auto Seek and Store stations	10	Device information	24
Select memory bank	10	System Settings	25
Sound settings	10	Common settings	25
Sound settings	10	Navigation software setting	25
Equalizer settings	10	Backlight setting	25
Audio distribution (fader/balance)	10	Radio setting	26
Navigation Function	11	Default volume setting	26
Navigation settings	12	Steering Wheel Learning	26
Take me home	12	FLAC Codec	26
Route	12	Memory clean	26
Favourites	12	Useful information	27
History	12	Warranty	27
Navigation settings	13	Service	27
Phone Feature	13	Connection Diagram	28
Making a call via Bluetooth	13	USB Support Files	29
Dialling	14	FCC information	32
Answer a call	14		
View Call History	14		
View Phone Book	14		
Play Music	15		
Bluetooth Music Function	15		

Safety notes

The car audio system is manufactured according to recommended and established safety guidelines in a state of the art facility. Even so, dangers may occur if you do not observe the safety notes in their instruction manual.

These instructions are intended to familiarise you with the most important functions. A detailed explanation can also be found on the website under the URL: <https://www.blaupunkt.com/in>

- For best results, please read the user manual carefully and completely before using the car audio system.
- Always keep the user manual accessible to all users.
- Always handover the car audio system to any third party along with these instructions.
- In addition, observe the instructions of the devices used in combination with this car audio system.

Symbols used

Below are the symbols used in this user manual, please go through them carefully:



CAUTION:

Warns about possibilities of any injuries that might occur.



DANGER:

Warns about damages to the DVD/CD drive (Not applicable to all Series 900 Model)



LOUD VOLUME:

Warns about high volume



The CE mark confirms the compliance with EU G directives.

- ✓ Identifies a sequencing step
- Identifies a listing

General Warning

To avoid any injury or damage to yourself, your car and others, please make sure to do as following. Observe the following note to protect yourself against injuries:

- **Do not modify or open the device.** Do not do any unauthorised modification to the device. In case you need any assistance, please visit the nearest services centre. The device should be open by an authorised person only.
- **Use as Directed:** this car audio system is intended for installation and operation in a vehicle with 12V vehicle system voltage and must be Installed in a 2DIN slot. Observe the output limits of the device. Only an authorised specialist should perform repairs and installation, if necessary.

- **Installation Instructions:** You may only install the car audio system yourself if you are experienced in installing car audios systems, and are very familiar with the electrical system of the vehicle. For this purpose, observe the connection diagram at the end of these instructions. For self-installation make sure you have the right tools with you.
- **Use your device in such a way that you can always safely control your vehicle.** In case of doubt, stop at a suitable location and operate your device while the vehicle is parked. As the driver, you must not use the applications that will distract you from traffic (depending on the scope of functions of the device, e.g. viewing videos, searching for a destination) (Navigation equipped radios and other downloaded application)
- **Follow driving recommendations during the route guidance only if you are not violating any traffic regulations:** Traffic signs and traffic regulations always have priority over driving recommendations.
- **Always listen** at moderate volume to protect your hearing and to be able to hear warning signals (e.g. police sirens and other external alerts while driving). During mute phases (e.g. when changing the audio source), changing the volume is not advisable. Do not increase the volume during this mute phase.
- **Do not ingest the battery, chemical burn hazard**
 - The remote control is provided with a coin/button cell battery. This battery is charged and if this button battery is swallowed, it can cause severe internal burns & may lead to death in 2 hours.
 - Keep new & used batteries away from the reach of children.
 - If the battery compartment does not close securely, stop using the product & keep it away from the reach of children.
 - If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

Road safety

Observe the following notes about road safety:

To avoid any injury or damage to yourself, your car and others, please make sure to do as following. Observe the following note to protect yourself against injuries:

- Before using this unit, please read all related instructions carefully.
- Any damage to this unit caused by improper operations will void the warranty.

- In order to drive safely and not break traffic rules, please do not watch videos or operate the unit while driving.
- The below-listed applications while driving the vehicle may divert your attention from the traffic situation and may lead to serious accidents:
 - Using the navigation feature like entering the destination address
 - Video playback or watching any kind of video
 - Usage of internet via the browser
 - Use of connected phone via PhoneLINK
 - Using Play Store or any other installed application via Play Store
- You are advised to refrain from any activity which could possibly divert your attention while driving. The best way to use these applications is when your vehicle is parked in a safe location.
- To avoid short circuit, please do not dispose the unit into the water and please do not place or leave any kind of metal object (such as a coin or metal tools) in the unit.
- Please operate the unit as per this Manual, it is not allowed to open the unit for maintenance; In case if maintenance is required, please seek professional help.
- After the car engine is off, please do not use the car audio for a long time, otherwise, the battery could be drained.

Instructions to read this User Manual

Illustrations are used in this manual to explain operations and precautions. The illustrations used in this manual are only for reference, please take the actual unit as standard.

Marks



Mark for important preventive measures; please read carefully to prevent any injury.



Mark for a special explanation, auxiliary interpretation, imitation and references.



Mark for additional information to operate this unit. Warm notes: When there is any difference between the Manual and the actual unit, please take the actual units as standard.

Declaration of conformity

Blaupunkt India Pvt. Ltd. declares that the device complies with the basic requirements and the other relevant regulations of the Directive 1999/5/EC. The declaration of conformity can be found on the website under www.blaupunkt.com

Cleaning notes

- Solvents, cleaning and scouring agents as well as dashboard spray and plastics care products may contain ingredients that will damage the surface & screen of the audio system.
- Use only a dry or slightly moistened cloth for cleaning the audio system.

Disposal notes

- Do not dispose of your old unit/batteries in the household trash.
- Use the return and collection systems available to dispose of the old device, the remote control and exhausted batteries.



Scope of delivery

The scope of delivery includes:

- Car audio system
- Remote control (Including battery)
- GPS antenna
- External Bluetooth microphone
- Small parts set, installation material
- Screws and fasteners
- Connecting cables


Placing the device in operation

Switching on/off with the touch button


To switch-on. Touch the  button (For switch off, hold the  button pressed for more than 2 seconds).

Turn the unit on/off with ignition switch

Turn the unit on:


When the ignition switch is at ACC ON position, press the button  on the panel to turn the unit on.

Turn the unit off:

When the unit is ON, long-press the button  on the panel for more than 2s, to turn off the unit.

Main menu (Home)


In the main menu, please touch the buttons on the touchscreen to call up different sources and operating modes


In any source, press the  button. The main menu (home page) is displayed. As long as you do not select a new audio source, the last active audio source continues to play. **Note:** The icons used in these instructions are intended to facilitate the explanation and actual details may vary in your device.

Volume


You can adjust the volume in steps from **0** (minimum) to **40** (maximum).


Touch the button **+** to raise volume and **-** button to lower the volume

You can mute the car audio system by touching the  icon while playing music.

Briefly press the  button to unmute the device or to return the previous volume.

Main Interface

After the unit is turned on, the system will enter Radio mode by default, then tap the icon  to enter the main interface.



1. Go to the previous page
2. Go to home page / Main menu
3. See history of pages opened
4. Displays the location icon
5. Displays Wi-Fi icon
6. Sound equalizer settings
7. PhoneLINK
8. Bluetooth music
9. Aux-IN
10. Open web browser
11. Start navigation
12. Play music from file
13. Connect via Bluetooth
14. Play FM/AM Radio
15. Manage System Settings
16. Access All Apps on Device





17. Play videos from file
18. View pictures from file
19. Steering wheel control
20. File explorer
21. Manage device settings



- 22. View clock / Set time
- 23. View/set Live wallpapers
- 24. Blackout screen
- 25. View wallpapers

Tap the icon [Screen Off] in the main interface to turn the screen off; then tap any area of the screen to turn the screen on. This is the recommended screen while driving; this will not distract the driver while the vehicle is in motion.



The grid icon at the bottom is a quick view to all tabs.
(To see more options swipe on the screen)

- 1. Wallpaper settings
- 2. Video settings
- 3. System Settings
- 4. Steering wheel control
- 5. Lunch radio
- 6. Open Play store
- 7. View pictures
- 8. PhoneLINK
- 9. Phone Make / Receive Calls
- 10. Play Music
- 11. Navigation
- 12. Live wallpapers
- 13. File explorer
- 14. Sound equalizer
- 15. e-Manual

Radio function

Radio function operation

Touch the icon [Radio] in the main interface to enter the Radio interface.




Setting the reception area

This car audio system is designed for operation in different regions with different frequency ranges and station technologies. The factory default of the reception area is 'EUROPE'. If you operate the car audio system in Asia, you may leave the setting to 'EUROPE' to set a suitable reception area on the menu:




- On the home page, press the (System Settings) icon. The settings menu is displayed.



- At the top area of the Settings menu. Press the (General) button.

- Select the 'Radio' option
- The current setting is displayed as 'EUROPE' region'. Please leave it at the current setting.



- Select on the Radio region button to display the list of available reception areas.
- Select the desired reception area by double clicking.
- The list is hidden, the selected reception area is set.
- The main menu is displayed again.

Tuning Into a station

- Briefly press the (Tuning) button once or several times to change the frequency in increments.
- You can select broadcast frequency directly by touch and drag on the frequency bar.
- The frequency selected is played back on the radio.
- Press the (Tuning) button for approx. 2 seconds to start station seek tuning.
- The radio tunes into the next receivable station.

Note: For the reception area Europe: In the FM waveband, only traffic information (TA) stations are tuned into if the priority for traffic information feature is switched on.

Storing stations manually

- Select the desired memory bank with the FM/AM button.
- Set the desired station.
- Press one of the memory buttons for approx. 2 seconds to store the current station at the button.




- The station is stored and can be switched by selecting the desired station.

With this device, you can automatically search for and store 6 FM stations offering the strongest reception in the region in the current memory bank. Any previously stored stations in this memory bank are deleted in the process.

Scanning stations



You can use the scan function to play all the receivable stations of the current wave band for a few seconds.

Long press the  button. The seek tuning searches for stations in the current waveband. Each receivable station is played for a few seconds in the process.



Band Switch

Tap the band icon **FM/AM** to switch the radio bands among FM1/FM2/FM3/AM1/AM2.

Tune and Seek

Short press the icon  to tune point by point; Long press the icon  to seek manually; It will stop seeking when a station is sought.

Auto Seek and Store stations


Long-press the icon  to auto seek, and auto store the sought stations. During seek, tap the icon  again to stop seeking.

18 stations will be stored in FM band (6 stations in FM1 / FM2 / FM3 each band); 12 stations will be stored in AM band (6 stations in AM1 / AM2 each band). The system will stop seeking after one-circle seeking.

- Start radio mode
- Select memory bank
- Tune into a station

Select memory bank

On the home screen, you will find the 'Radio' icon. Touch the 'Radio' icon to enjoy the radio on the go. Different memory banks and wave bands are available. Up to 6 stations can be stored in each memory bank. FM1+FM2+FM3/AM1+AM2. Press the **FM/AM** button repeatedly until the desired memory bank is displayed.



Sound Setting

Equalizer settings:

In the main menu or on the control bar of the current audio source. Press the (Equalizer) button. To manage the Equalizer settings, select 'EQ' from the main menu.



The equalizer menu is displayed. You can adjust the equalizer for all sources. The 10-band equalizer allows the user to fine-tune reproduced sound to suit individual taste.



This option offers simplified sound turning and displays 6 bands. The 'Custom' setting allows you to fine-tune the music just right to your taste. The options available to you are listed below.


Click on  **CLASSICAL**  left & right arrows to choose the right EQ setting for the genre of music.

- Pop
- Rock
- Classical
- Jazz
- Flat
- Custom

Audio Distribution (fader/balance)

Press the **BAL/FAD** to adjust the Balance (L-R) & Fader (Front-Rear) bands according to the passenger preferences.


- Left Front
- Left Rear
- Right Front



- RightFront
- Touch the blue dot to adjust your preference OR use the arrow keys to adjust your preference.
- The Bal and Fad reading will be displayed on the top right of the screen.
- Once you have achieved your desired setting touch the return tab to return to the previous menu. It's recommended to leave the Balance/Fader at 0-0.
- You can also use the Touch the button + to raise volume and – button to lower the volume on the device panel to adjust the volume

OR

- Slide down from the upper-right area of the main interface to adjust sound volume directly.



Navigation Function

This device is equipped with navigation on board. Insert the mSD card (sold separately) into the map slot in front and type your destination. Follow turn-by-turn voice-guided commands to get to your destination hassle-free.

Because of the rapid development of the urban construction and the road planning, the navigation map company constantly updates the navigation map.

If the route directed by the navigation map is found to not conform with the actual road condition or the actual traffic control condition, please drive the car as per the actual road condition, traffic control and traffic rules.

Steps to open the navigation:

- Insert SD card in the Navigation Slot
- Tap the icon [Navigation] in the main interface to enter the navigation interface.



- Enter the desired destination using the input key.
- Enable to find the destination via various search functions of the navigation software.




- After the destination is set, the system will plan the route and begin navigating.




In the area that the driver is familiar with, it may be more advisable for the driver to drive by himself than to rely on the navigation system.

Navigation settings

There are five icons to enhance your navigation experience and ease your everyday use of the navigation feature.

Click on the icon  at the bottom left to expose the features listed below:



- Take me home: Auto detects your location and plans your route back home
- Route: Show the trip stats
- Favourites: You can save your favourite/frequently travelled locations
- History: Shows your trip history
- Setting: General navigation settings


Touch on the icon the access the rich navigation features:

Take me home:

Set the address and use this option to plan your route back to home.


Route:

This tab shows vital information about your current trip in session.




Favourites:

Here you can store your favourite or frequently travelled destinations. This will save you time in inputting the address every time.




History:

Check your travel history and places travelled. This is quite helpful in computing the travel done by you in the recent past.



Navigation setting:

Several settings are available to may your ride safer and comfortable. Like the Speed alert and the safety camera alert. Please keep them checked for a good ride. You can also deactivate the options by unchecking them.



In case of error

In normal condition, the error of satellite signal reception is about 7 meters, while in several situations, some error may still occur after the auto-correcting of the software, at these moments, the driver should pay attention to the road condition and drive according to the actual road condition.

Note: Using environment of navigation system can be complicated and varying, the system operation may have some issues (such as failing to enter the map interface, no image etc.) when encountered by a large electromagnetic disturbance. It will require a re-start operation to deal with these issues.


Phone Feature

Please be aware that using a hand-held phone while driving is an offence. You can use this device to make & receive call hands-free. However, it is suggested to make minimal use of this feature & talk only when in great need of talking to someone. Talking while driving may divert your attention from traffic conditions ahead.

Making a call via Bluetooth

For the first time to pair the mobile and the unit, it is required to operate as below instructions:

- Turn the Bluetooth of the mobile on;
- Search the Bluetooth device with the mobile or the unit, and connect - Device name is C900;
- A prompt message will show on the mobile, input the password 0000 and Confirm on the mobile;
- After pairing successfully, the system will enter the interface below:




- ✓ After the unit is powered off and on, the Bluetooth of the unit will connect the mobile last disconnected.
- ✓ After pairing successfully, the icon [📶] showing the connecting status on the upper-right corner of the screen will turn White.
- ✓ Device name and the pin to connect is available on the interface


It is required to turn on the function "Visible to all nearby Bluetooth devices" on the mobile, and then the unit will be able to find the mobile Bluetooth device.

Dialling

After the mobile is connected to the unit successfully, input a series of numbers via the numeric buttons on the screen, and then tap the icon [📞] to make a call. During dialling, if a wrong number was input, you may tap the icon [⏮] to delete one by one, or long-press the icon [⏮] to delete all. As is shown in below interface:



You may also make a call via your mobile directly.



Touch the [📞] icon, the numeric keyboard will pop up. Touch this icon again & the number keyboard will disappear;

Touch the [📞] icon to hang up a call.

Tap the [📞] icon to switch call audio between mobile microphone and car audio.


Tap the [📞] icon to activate Mute mode.

You may also hang up a call via your phone directly.

Answer a call

When there is an incoming call, the system will switch to Bluetooth interface automatically

As shown in the interface below:




Tap the [📞] icon to answer a call.

You may also answer or refuse a call via your mobile directly.

View Call History


Tap the [📞] icon in Bluetooth interface to enter the call history interface as shown below:



Touch the [📞] icon to switch between Outgoing call / Missed call / Incoming call.

View Phone Book


Touch the [📞] icon in Bluetooth mode to enter the below interface.




Note: After Bluetooth is connected successfully, the system will send a request message to the mobile [Android would like to access your contacts and call history. Give access to Android?] Press Yes on your mobile, the unit will begin to download the phonebook; After downloading successfully, the call history & phonebook of the mobile will display on the unit.

Play Music

Touch the music icon - this application is for music stored on the device or USB.



Once you insert a USB drive the device will auto search for music files and display option to play music and browse playlist.



☞ Touch this icon, you can shuffle your music play list.

⏮ Touch this icon to play the previous song.

▶ Play or pause the currently played song

⏭ Move to next song in the playlist

🔍 Quick search the song of your choice.


📁 Open and browse the available playlist of songs.

Bluetooth Music Function

The Bluetooth music function allows user to directly stream music stored on their mobile devices to the radio.




Touch the [Bluetooth music] icon to enter the following interface.



Depending on the model of the mobile phone, you may need to press start to play music files via your mobile.

USB Music Function

The music formats supported by this unit include MP3, M4A, WAV, AMR, WMA, OGG, AAC, MID etc.



When playing a music file that is not supported, the system will prompt "fail to play as the file format is not supported". Touch the [Music] icon in the main interface to enter below interface:

Tap the icon [⏮] / [⏭] to play previous/next song.

Tap the icon [⏮] to switch between Pause/Play

USB data carrier

This device features a USB port (Type A) at the Rear.

Basic information

Costa Mesa 900 comes equipped with 3 Rear USB ports (Type A). The Hardwired USB port allows for quick charging of portable devices (up to 2A) and the other 2 via a patch harness upto 1.5A.

For safety reasons, playback of movies and images on the integrated monitor is allowed only while the vehicle is parked and the handbrake is applied. The BRAKE'cable must be connected with the handbrake connection of the vehicle (see Connection diagram at


the end of these instructions). Movie playback on a Rear Seat Monitor is possible while driving.

Notes:

- Blaupunkt cannot guarantee flawless function of USB data carriers and microSD cards available on the market.


Audio playback from USB

The principles of audio playback (MP3/WMA) from data carriers are identical for all sources. Select the desired source via the main menu. The device changes to the desired source and the playback starts.



Video playback from USB

Select the desired source from the main menu. The device changes to the desired source and the playback starts.




Important: Please do not watch video while driving.


General Feature

Instructions on PhoneLINK

The PhoneLINK feature mirrors the phone screen on the head unit. Please note PhoneLINK feature is available for Android/iOS phones only for this model. You can access apps, emails & messages while on the go.



Touch the icon [PhoneLINK] on the main interface to enter the interface below:



PhoneLINK.: New PhoneLINK feature allows you to connect your Android Smartphone to this Blaupunkt. Touchscreen radio using your mobile phone data cable.

Enjoy all functions & applications on your Android phone via the in-dash radio.

- View your smartphone images on the radio display
 - Play music from your phone
 - Navigate without touching your smartphone (google maps)
 - Access your phone contacts & apps
 - Check your Email / Messages
- *Check compatibility with your Android phone before purchase.

To activate PhoneLINK please follow detailed instructions on the next paper to turn on USB debugging.


iPhone PhoneLINK operation

- Turn on the hotspot on the iPhone:
- Turn on the iPhone hotspot in [Settings], record the hotspot name and password;
- Turn on WiFi in [Settings] on the unit, search the iPhone hotspot, input password and connect.
- Open the Shortcuts control bar on the mobile, find Airplay - EC - Mirror to turn on Mirror switch and connect.

Note: After the Mobile and the unit connected successfully, the unit will display the mobile screen.

Please follow the below instructions to turn on debugging on your phone.
Some steps may be different on different phones please also refer to your mobile phone instruction manual.

1. Go to Settings




2. About Phone





3. Build Number




4. Tap on Build no for 6 to 8 times




5 & 6. You will now see Developer mode activated under Developer Option




7. Turn on Developer Option



8. Switch on USB Debugging, Say OK to the message




9. USB debugging is now ON







Powered by Android & featuring the Google Play store, the Brilliant Costa Mesa 900 is Wi-Fi ready to connect to any available Hotspot letting you enjoy online content like Youtube, web browsing and your favourite Internet radio on the device itself.




To access the Play Store, Open quick menu. You will find the Play Store Icon. This will launch the application.




For the initial setup, add your existing Google account. In case you do not have one, you can create one right here.



Fill in the details and click on 'Accept' to proceed further.



You will get a default prompt to 'Automatically back up device data'. You may choose or skip this option.



You are ready to enjoy Play Store on the move. Left swipe for more options and Play Store settings.

Google Play (previously Android Market) is a digital distribution service operated and developed by Google. It serves as the official app store for the Android operating system, allowing users to browse and download applications developed with the Android software development kit (SDK) and published through Google.

You can enjoy a variety of apps, which can be downloaded through Google Play.




The navigation system is equipped to work with the regional navigation system - MapmyIndia (via mSD card) as well as Google Maps (via PhoneLINK).


Please Note: The Play Store service is a complimentary service. The service provider reserves the right to withdraw the service without giving any prior notice.

Browsing the internet

You can browse the internet using the browser option shown below.




In order to browse the internet to follow the steps shown below.



- For the first time use, you will get the screen shown above.
- Add an existing account or set up a new account
- Then using the touchscreen and input keys you can browse the web.
- Check your emails and view websites.


Videos:




Click on the 'Video' icon on the main interface to launch the videos from the connected USB drive.

The available videos will be displayed here. Select the video to be played.

Pictures




You can view pictures saved in the USB and other collaborative locations. Click on the [Pictures] icon to launch this feature.



To view pictures from your files select 'Folders' You can also view pictures from you other sources like Moments, Dropbox, Google Drive and Picasa.

SWC (Steering wheel control)



Steering wheel control allows you up to eight functions that can be operated via existing steering wheel-mounted controls. This requires assigning the desired function to the buttons on the SWC.

Note: The SWC function operates with analog control signals, depending on the vehicle type an additional interface may be required.


- Select the SWC icon from the main interface
- Assign the desired function up to 8 placeholders (Select any from 1 to 8)
- The assigned placeholder is identified by the check mark and the selected function is identified by placeholder number
- Repeat the steps to assign the additional function to the SWC controls
- Thereafter assign the relevant placeholders to the buttons of steering wheel-mounted controls




- Tap on 'Begin Learn' to start
- Placeholder 1 and the assigned function are displayed
- Press any button of the remote control for approximately 1 second
- The displayed function is assigned to the button being pressed
- Tap on the ➡ to assign the next function
- You can tap the ⬅ to return to a previous function and reassign if needed.

File Explorer


The 'File Explorer' icon on the main interface allows you to browse the content of your files used on the device



The 'Classify' tab can help you quickly identify the files you are looking for based on its classification. The options available range from Apk, Image, Video, music or any other type.



When you tap on the 'sd card' tab you get to see content from the different folders you have. Select the desired folder to access your files.




The 'udisk3' tab allows you to see different files available to you and makes access easier.

Clock

Touch the clock icon to display the clock screen.




The clock will continue displaying until the user touch on the screen or turns the device off.



Live Wallpapers




Live wallpapers feature allows you to select dynamic wallpapers as per your preference. Select the 'Live wallpapers' icon from the main interface



List of live wallpapers will be displayed. Select your preference, the live wallpaper will be set.

Wallpapers

Wallpapers feature allows you to select static wallpapers as per your preference. Select the [Wallpapers] icon from the main interface.



List of wallpapers will be displayed, swipe to explore more. Select your desired wallpaper, swipe left or right to preview the wallpapers

After you select a wallpaper, tap the icon [Set wallpaper], the selected wallpaper will be set.

AUX in



Connect the video RCA to video input socket and the audio RCA's (L+R) to the audio input RCA's, tap the icon [AUX-IN] in the main interface to enter AUX-IN interface.


Warning: Do not watch Video while driving

Blackout


There is a blackout feature in this radio. Tap on [Blackout] tab to enable a dark screen. The music continues to play in the background and the screen appears to be off. This can help you concentrate while driving at night.



Device Settings




In the 'Device Settings' icon you will find a various settings that you will need to access from time to time.




The important options available here are

- WiFi Settings
- Portable WiFi Hotspot Settings
- Storage info
- Apps
- Adding an account
- Language input settings
- Date & time settings


WiFi Settings




- Switch on the 'WiFi' option 'with this button . This will search and display all the available connections of the range.
- If you get a prompt for a password 'Input password', Enter password at this time.
- Click on connect to establish secure connections
- In case you get an error, touch the 'forget' tab and try to connect again.
- Once the connection is established the device

connects automatically for all subsequent attempts.

Portable WiFi Hotspot Settings




With the [Portable WiFi hotspot option], you can create an Internet connection to connect your mobile or the mobile of your co-passenger. Here are the steps listed.

- Switch on the [Portable WiFi hotspot option] with the button shown here . Please note: Once the 'Portable WiFi hotspot option' is checked the WiFi on your device will auto disconnect.
- You should get a pop-up window. This should show the connection details
- Check the [Show Password] option, The password will be displayed. Enter this password in your mobile to connect.
- You can share the password with the fellow passengers allowing them to connect to the Portable WiFi hotspot on your device.

To change the [Portable WiFi hotspot] password.


- Check the 'Show Password' option.
- Touch the password, an input key will appear
- Choose the password of your choice & select 'Done'
- The password will get changed.

Storage info




Under the [Storage] you can see the space available in the internal storage.

Apps




With the 'Apps' tab user can get quick access to all the Apps available and downloaded and installed from Google Play Store.

Adding an account




'Add an existing Gmail account in here; in case you do not have one you can also create a new account right from the option available in this section.

Language input settings




Manage you Language and keyboard input options form the 'language and input' tab.

Date & time settings



- You can choose to synchronize the date and time with the GPS by keeping the adjacent box checked. If you wish to set your own time, then uncheck the tick and the set date and set time will be activated. Input your desired date & time.
- You can choose to use the 12 hours or 24 hours' time display as per your preference by a tab on the button at the bottom.

Device information



Under the 'Device information' you can get the following details:

- Device model number: Costa Mesa 900
- Android version: 6.0
- Memory capacity: 1GB| 16GB
- Storage capacity: 16 GB

System Settings




In the 'System Settings,' you will find a various settings which you will need to access from time to time. Tap the icon the explore and make the required settings.

General setting you the following options are available, all of them are explained further in the manual.

- Common settings
- Navigation software setting
- Backlight setting
- Radio setting
- Default volume setting
- Steering Wheel Learning


Common Settings



Under the 'Common settings,' you can do the following, touch to activate and deactivate.


- Parking settings
- Illumination
- Beep settings
- Reverse Camera Monitor
- Reverse Audio Mute

Navigation Software Setting




- Navi Software Settings' allows you to select the Map source, manage Navigation audio mixing & adjust the volume of voice guidance prompt.
- Touch the Navigation mixing to activate & deactivate.
- Drag the bar to increase & decrease the voice guidance prompt volume

Backlight setting




The intensity of the backlight can be set by moving the seek bar towards the left or right.

Radio Setting




- The current setting is displayed as 'EUROPE' region'. You should leave it to the current setting.
- Select on the Radio region button to display the list of available reception areas.
- Select the desired reception area by double-clicking.
- The list is hidden, the selected reception area is set.
- The main menu is displayed again.

Default Volume Setting



Under the [Default setting], you will find the start up volume tab. Scroll on the seek bar to adjust the default volume.

Steering Wheel Learning




Along with the [SWC] icon available on the main interface, you can manage the Steering wheel control form this tab. SWC allows you up to 8 functions that can be paired via existing steering wheel mounted controls. This requires assigning the desired function the buttons on the SWC

FLAC Codec

Free Lossless Audio Codec: an audio format. Flac allows you to play uncompressed audio files without any loss. This device can read FLAC files (Via front USB).

Memory Clean



Touch and drag the screen form the top down, you will get quick options which include [Memory Clean] you can delete the cache which will improve the performance of the device.

Useful information

Warranty

We provide manufacturer's warranty for products bought within the India. For devices purchased outside the India, the warranty terms issued by our respective responsible domestic agency is valid. Warranty terms can be viewed at www.blaupunkt.com.

Register **ONLINE** within **15 days** of **PURCHASE** to activate **WARRANTY**.

The procedure to activate the warranty is given below;



Thank you for buying **Blaupunkt**

Model: Palm Beach 550

Serial No.:

BP76103550000001



Please activate the e-warranty within 15 days of purchase.

To activate your e-warranty, please follow the below steps:

Step 1. Please send SMS

SERIAL <space> <serial number> to 07760962759

Step 2. In response to the sent SMS, you should receive back a link via SMS, please **Click** on it

Step 3. Complete a simple form to register your product & activate e-warranty.

E-user manual is available at www.blaupunkt.com or upon completion of registration, follow the link at the bottom on the page to download.

Should you require further assistance, please call: Customer Support 1800 209 6820

Thank You!!

Service

If your device should need service, you can find information about service partners at


www.blaupunkt.com

OR

Email: Support@blaupunkt.in

OR

Call **1800 209 6820** for the location of an authorized service center near you.



①	WIRE	COLOR	FUNCTION
	1	Purple	Right Rear speaker ⊕
	2	Purple/black	Right Rear speaker ⊖
	3	Grey	Right Front speaker ⊕
	4	Grey/black	Right Front speaker ⊖
	5	White	Left Front speaker ⊕
	6	White/black	Left Front speaker ⊖
	7	Green	Left Rear speaker ⊕
	8	Green/black	Left Rear speaker ⊖

③	WIRE	COLOR	FUNCTION
	14		SWC
	16		
	17		

②	WIRE	COLOR	FUNCTION
	1	NC	NC
	2	Brown	NC
	3	Orange	NC
	4	Yellow	ACC power
	5	Blue	Automatic antenna
	6	Green	ILL
	7	Red	B+
	8	Black	GND

Note: Be sure the unit is connected to a 12V DC power supply with negative ground.
Remark: For users, please take the actual function of product as the standard.

Multimedia Support list
Part I: Multimedia Processing

Video Files				
Video Decoding	Profile	Max Resolution	Performance	Max Bit Rate
MPEG1	MP/HL	1920x1080	1080p@45fps	100Mbps
MPEG2	MP/HL	1920x1080	1080p@45fps	100Mbps
MPEG4	SP/ASP L5	1920x1080	1080p@45fps	100Mbps
xvid	N/A	1920x1080	1080p@45fps	100Mbps
H.264	BP/MP/HP	1920x1080	1080p@45fps	60 Mbps
AVS/AVS+	JiZhun	1920x1080	1080p@45fps	30Mbps
H.263	BP	1920x1080	1080p@45fps	100Mbps
WMV1	N/A	1920x1080	1080p@45fps	100Mbps
WMV2	N/A	1920x1080	1080p@45fps	100Mbps
WMV3/VC-1	SP/MP/AP	1920x1080	1080p@30fps	100Mbps
VP6	6.0/6.1/6.2	1920x1080	1080p@45fps	40Mbps
VP8	N/A	1920x1080	1080p@45fps	40Mbps
MJPEG		1920x1080	1080p@30fps	60Mbps
Sorenson Spark	N/A	1920x1080	1080p@45fps	100Mbps
VP9		1280x720	720p@30fps	2Mbps
H265		1280x720	720p@30fps	2Mbps

Video Encoding	Max Resolution	Max Bit Rate	Max Frame Rate	Remarks
JPEG	4096 x 4096			4:2:0/4:2:2 Support 16M pixel
H.264	1920x1080		1080p@45fps	Simple/Main/High Profile CAVLC/CABAC

Audio Files				
Codec	Profile	Max Bit Rate	Max Sample Rate	Remarks
MP3	All	320Kbps	48000	
OGG	Q1 - Q10	500Kbps	48000	
FLAC	Level 0 - Level 8	1.60Mbps	48000	
APE		950Kbps	48000	
AAC		448Kbps	48000	
AMR			48000	

T3 Multimedia support list
Part II. Container

Video Files					
Container	Audio	Video	Max Bit Rate	Multi Audio Switch	Subtitle
MKV	MP3	MPEG2	80 Mbps	Support	UTF8/ASS/SSA/ ACSI/II/sub
		WMV9			
	MP3	Xvid			
	MP3	H.264			
	AAC	H.264			
	FLAC	H.264			
	OGG	H.264			
AVI	MP3	Xvid	80 Mbps	N.A	UTF8/ASS/SSA/ ACSI/II/sub
	MP3	H.264			
	AAC	H.264			
	MP3	MPEG2			
	AAC	WMV7/8/9			
	AAC	VC - 1			
	MP3	MJPEG			
TS/TP	MP3	H263			
	MP2	MPEG2	50 Mbps	Support	UTF8/ASS/SSA/ ACSI/II/sub
	MP3	MPEG2			
	AAC	MPEG2			
	MP3	H.264			
	AAC	H.264			
	MP3	VC - 1			
	AAC	VC - 1			
MP4/M4V	MP2	Xvid	80 Mbps	N.A	UTF8/ASS /SSA/ACSI/II/sub
	MP3	H.264			
	AAC	H.264			
MOV	MP2	Xvid	80 Mbps	N.A	UTF8/ASS /SSA/ACSI/II/sub
	MP3	H.264			
	AAC	H.264			
VOB	MP2	Xvid	80 Mbps	Support	UTF8/ASS /SSA/ACSI/II/sub
	MP3	H.264			
PMP	MP3	Xvid	80 Mbps	N.A	UTF8/ASS /SSA/ACSI/II/sub
	AAC	Xvid			
	MP3	H.264			
	AAC	H.264			
MPG	MP1/2	MPEG2	80 Mbps	N.A	UTF8/ASS /SSA/ACSI/II/sub
	MP1/2	MPEG2			

T3 Multimedia support list

Part II. Container

Video Files					
Container	Audio	Video	Max Bit Rate	Multi Audio Switch	Subtitle
M2TS	MP3	MPEG2	50 Mbps	Support	UTF8/ASS /SSA/ACSII/sub
	MP3	H.264			
	AAC	H.264			
	AAC	VC - 1			
FLV	MP3	H.264	80 Mbps	N.A	UTF8/ASS /SSA/ACSII/sub
	AAC	H.264			
	MP3	H.264			
	AAC	H.264			
	MP3	VP6			
	AAC	VP6			
WMV		VC - 1	80 Mbps	N.A	UTF8/ASS /SSA/ACSII/sub
		VC - 1			
		WMV7			
		WMV8			
WebM	MP3	VP8	80 Mbps	Support	UTF8/ASS/SSA/ ACSII/sub
	AAC	VP8			

Part III. Photo

	Container	Profile	Max Resolution	Remarks
PHOTO	JPEG	Baseline	65536x65536	UTF8/ASS /SSA/ACSII/sub
	BMP	All	2.5M pixels	
	GIF	89a/87A	2.5M pixels	
	PNG	All	2.5M pixels	

This device incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.

Windows® und Windows Media® are registered trademarks of the Microsoft Corporation in the U.S.A. and/or other countries.

This product is protected by certain intellectual property rights of Microsoft. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.



Manufactured under license from Dolby Laboratories.

"Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 centimeters between the radiator and your body.

Blaupunkt India Private Limited
47, Atlanta Society, Nariman Point
Mumbai- 400 021. Maharashtra. India.
www.blaupunkt.com

