

# Use and Care Manual

## Proper Usage

### Weight Limits:

Lid bench: 400 lbs max (seating only).

Interior storage: 300 lbs max (distribute weight evenly).

Locking Lid: Use a padlock (not included) to secure valuables.

Moving the Box: Engage wheel locks when stationary; tilt slightly to roll on uneven surfaces.

## Cleaning & Maintenance

Wicker Exterior: Wipe with a damp cloth and mild soap; avoid abrasive cleaners.

Steel Frame: Check for rust annually; touch up scratches with outdoor-grade paint.

Waterproof Liner: Remove debris from the zippered polyester bag and air-dry if wet.

Mesh Pocket: Hand-wash with cold water and air-dry to maintain shape.

## Storage Tips

Off-Season: Empty the box, clean thoroughly, and store in a dry, covered area.

Inclement Weather: Keep the lid locked during storms to prevent water seepage.

## Important Notes

Color Variations: Natural wicker tones may differ slightly from images due to lighting.

Safety: Never exceed weight limits or stand on the closed lid.