




**CONNECTIONS
VERBINDUNGEN
LIENS**




H-PATTERN SHIFTERS




STATIC SHIFTER




SEQUENTIAL SHIFTER



HANDBRAKE



PEDALS



USB TO PC / CONSOLE

IMPORTANT!

- EN** Use only the straight USB plug packaged with the CSL Elite Wheel Base to avoid damage to the USB port.
- DE** Verwenden Sie ausschließlich das mitgelieferte Kabel mit dem geraden USB-Stecker um Schäden zu vermeiden.
- FR** Utilisez uniquement la prise USB incluse avec la CSL Elite Wheel Base pour éviter d'endommager le port USB.

FANATEC®

CSL Elite Wheel Base



QuickGuide

