

73*93MM

TWS-无线耳机

使用说明书

使用前请阅读说明书

S35

功能要点

- 开机使用前, 请先将充电盒及耳机充满。
- 插入充电线时同时给耳机和充电盒充电
- 耳机在充电盒内, 从充电盒中拿出耳机自动开机。
- 耳机放入充电盒内, 耳机自动关机。
- 无连接状态下, 耳机5分钟后自动关机。

自动连接:从充电盒中取出耳机, 耳机自动开机后, 待耳机绿白指示灯交替闪烁时, 打开设备蓝牙搜索蓝牙名称并点击完成连接。如果连接失败, 将耳机放回充电盒重复上述操作。首次连接后, 耳机开机自动回连上一次设备(设备蓝牙需开启)。

注意:1.耳机出厂时已完成初始化, 可直接取出进行相关操作。
2.连接成功后自动分配主副耳, 如无回连, 请再按"连接"操作一次

操作说明

以下功能左右耳机均可操作
【接听/挂断电话】

来电时单击任一耳机接听电话;
通话状态下单击任一耳机挂断电话,

【音乐播放/暂停】

单击任一耳机播放/暂停音乐。
注意:音乐播放器必须处于后台运行状态。

【上下换曲】

双击左/右耳机播放上/下曲

【音量加減】

三击左/右耳机音量加/减

【语音助手】

长按2S进入语音助手

维护和保养

您所购买的蓝牙耳机具有优良的品质, 为了延长使用寿命, 请确保您执行以下操作:

- 1.请不要尝试拆开蓝牙耳机或充电盒。
- 2.请将本产品放于干燥并远离高温暴晒、雨林潮湿和腐蚀性物品的地方。
- 3.请不要对本产品进行撞击、敲打、摔落、扭曲、浸水等破坏行为
- 4.请使用正规厂家生产并通过安全认证的充电器给本产品充电。



TWS Wireless Earbuds

User Manual

Please read the instruction manual before use

S35

Functional points

- Before starting up and using, please fully charge the charging box and headphones.
- plug in the charging cable while charging the headphones and charging box.
- The earphones are in the charging box. Take them out of the charging box and turn them on automatically.
- Put the headphones into the charging box and they will automatically turn off
- When there is no connection, the headphones will automatically shutdown after 5 minutes.

Automatic connection: Remove the earphones from the charging box, turn them on automatically, and when the green and white indicator lights of the earphones flash alternately, turn on the device Bluetooth to search for the Bluetooth name and click to complete the connection. If the connection fails, place the headphones back in the charging box and repeat the above operation. After the first connection, the headphones will automatically connect back to the previous device when turned on (the device Bluetooth needs to be turned on)

Attention:

1. The earphones have been initialized at the factory and can be directly removed for related operations.
2. After successful connection, the main and auxiliary ears will be automatically assigned. If there is no return connection, press "Connect"

Operating instructions

The following functions can be operated by both left and right headphones

- *Click on any earphone to answer the call when there is an incoming call;
- *Click on any earphone to end the call while in call mode.
- *Click on any earphone to play/pause music.
- *Double click on the left/right earphones to play up/down tracks
- *Three click left/right headphone volume increase/decrease
- *Long press 2S to access the voice assistant

Maintenance and upkeep

The Bluetooth earphones you purchased have excellent quality. In order to extend their service life, please ensure that you perform the following actions:

1. Please do not attempt to open the Bluetooth headphones or charging case
2. Please place this product in a dry and away from high temperature exposure, rainforest moisture, and corrosive materials
3. Please do not engage in destructive behavior such as hitting, knocking, dropping, twisting, or soaking this product
4. Please use a charger produced by a reputable manufacturer and certified for safety to charge this product.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.