





RÅDMANSÖ



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:




ALWAYS install anti-tip device provided.






NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

ALWAYS secure your television with an anchor device.

English




Read and follow each step of the instruction carefully.






10115896

1




2




159553

12x




10094681

4x




10109447

2x



10094656

4x




119976

2x



117434

12x




10094662

4x



108528

4x




10040242

3x



10047245


18x






10124242

2x


1




2




3




4




5




6




7




8



9





10




11



16x




12




2x




13




14




15




16




17




18






20



21






www.IKEA.com/secure-it



www.IKEA.cn/secure-it




22

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


A




Ø 8 mm
(5/16")




1




2



3




B




Ø 8 mm
(5/16")




1




2



3




C




Ø 3 mm
(1/8")




1




2




23




24




27




28





29




30












32




33




34




35



36



37



38

