ρTron



Bassbuds Plus True Wireless Stereo Earbuds


Instruction Manual

Button Operations:

Note: Please always carry the Charging case

along with the earbuds

MFB (Multi function Button)



- **2. Power OFF:** Press & hold the MFB for 5 seconds on left or right of earbud which will be followed by red light flashing or directly place both the earbuds into the charging case. You will also hear the voice prompt "Power OFF" before getting in off mode.
- 3. Next Song: Double click MFB on either
- 4. Previous Song: Click thrice on MFB either earbud
- 5. Play/Pause Music: Click MFB once on either earbud
- **6.Call Receive/Hangup:** Click MFB once on either earbud

- 7. Reject Call: Click MFB for 2 sec on either earbud
- **8. Google Assistance/Siri:** Long press MFB on either earbud for 2-3 sec.

Note: MFB stands for multi–function button of the earbuds.

Bluetooth Connection:

- 1. Turn on both the earbuds, both the earbuds will flash blue & red light alternatively.
- 2. Wait until both the earbuds gets match to each other. Once they get matched only one earbud will flash blue & red light alternatively.

 3. After matching L & R earbuds you will hear the voice prompt as "pairing" that means device is in "ready to pair" mode.
- 4. Turn on the Bluetooth of your phone or device.
- 5. Search for "pTron TWS" in the available Bluetooth device list and click to connect.
- 6. After successful connection you will hear the voice prompt "pTron TWS is Connected".

Re-connection:

After turned on, the earbuds will reconnect to the last paired device. If there's no prior connection history, or it fails to reconnect to any device then the earbuds will enter standby mode and wait for connection.

Connection Lost:

When your phone turns off the Bluetooth feature or is out of the wireless range. The earbuds will enter standby mode. If the connection is not restored within 5 minutes then earbuds will turn off automatically.

Auto Power Off:

The device will automatically shut down if there is no connection for 5 minutes or the earbuds battery gets discharged. Once the battery level of earbuds becomes low up to 10% it will prompt as "Battery low" and the red light will flash in every 5 seconds.

Note: Keep the earbuds on charging when you hear battery low voice prompt.

Charging:

- 1. To charge the earbuds, place them into the charging case at their respective locations. During charging, earbuds will flash steady Red light.
- After getting full charged earbuds light will turn to blue and then light will turn off in few seconds.
- 3. To charge the charging case plug the micro USB cable into the micro USB port of charging case. You can use any DC5V/1A adaptor for charging the case.
- 4. LED display will show the available battery percentage in the charging case.

Highlights of the Product:

- Hi-Fi stereo sound with bass
- 2. A2DP Audio Technology
- 3. Hands-free binaural call function
- 4. 12 hours playback time with Charging case
- Digital display charging case
- 6. Lightweight & ergonomic earbuds
- 7. Stereo and mono use

Troubleshooting:

- doesn't find the "pTron TWS" in your device
 then make sure that earbuds must be
 nearer to the device at 1 meter range.
 Earbuds must be flashing blue & red light
 alternatively on any one piece and if it is
 flashing only blue light for once in regular
 intervals that means earbuds are already

 (iii) Now turn of device and ad
 "pTron TWS".

 5. Google Assist
 Restart your p
 Google Assist
 6. Mono Use:
- connected with some other device.

 2. Auto-disconnection: Make sure that earbuds are fully charge to 100%.

 Reconnect your device after restarting your phone & Bluetooth earbuds otherwise reset

your phone Bluetooth settings.

1. Bluetooth not searching: If your phone

- Device connected but no music or call works: Check the settings of your Bluetooth connection and make sure that call & music function must be activated.
- 4. Single Earbud Plays: If only one earbud plays then follow the below steps.
- (i) Un-pair the previously paired "pTron TWS" from your phone or device & turn off Bluetooth of your device.

...

from the charging case & wait until they get matched to each other. (iii) Now turn on the Bluetooth of your

(ii) Now take out both the earbuds together

- (iii) Now turn on the Bluetooth of your device and add a new connection of "pTron TWS".
- 5. Google Assistant/Siri not working: Restart your phone or device or check the Google Assistant setting in your phone.
- Mono Use: Take out any one piece from the charging case & search "pTron TWS" on your phone or Bluetooth device and click to connect.

Disclaimer:

The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.

2

. .