

ABOUT THIS GUIDE

To take full advantage of the information in this guide, users must have training or experience working with the Niagara N4 software.



Parameter	Description
Software requirement	Niagara workbench. For compatibility information, refer to the latest software release notes.
	Google Chrome web browser
Modules	<ul style="list-style-type: none"> • honeywellTCThermostatWizard-rt • honeywellTCThermostatWizard-ux • honeywellTCThermostatWizard-wb • honeywellBacnetDeviceManager-rt • honeywellBacnetDeviceManager-wb • honeywellDeviceManager-rt.jar • honeywellDeviceManager-wb.jar

The TC Series wizard does not require additional licensing apart from the controllers or supervisor license.


The installation procedure for the TC500A and TC300 thermostats is the same. Configuring the TC500A is shown in this document for reference. The configuration procedure for the TC300 is the same as the configuration procedure for the TC500A.

1. Connect to the **Platform** and double click on the **Software Manager**.
2. Select and install the 'honeywellTCThermostatWizard' module. Status must change from "**Not Installed**" to "**Up to Date**."
3. Launch the station.



Adding the TC Series Device to the Station


Install the modules on the controller as described above and connect to the station.

**NOTE:**
The TC Series Thermostat Configuration Wizard is a BACnet device. Add and configure a BACnet network before adding it to the station.

- 1. Navigate to **Window > Side Bars > Palette** to open the palette pane. The palette pane displays on the lower-left side.



Fig. 2 Open Palette

- 2. Click on the  (Open Palette) option to display the palette window.
- 3. Type 'honeywellTCThermostatWizard' in the filter field, select the module and then click **Ok**.




Fig. 3 Search Configuration Wizard Module

- 4. Using the palette, navigate to the 'honeywellTCThermostatWizard' module in the workbench.



Fig. 4 Open Configuration Wizard Module


**NOTE:**
A user can use the workbench or a browser to configure the TC Series Thermostat Configuration Wizard via the configuration wizard.



Fig. 5 Device Selection

- 5. Drag and drop the TC500 or TC300 device under the **Station > Config > Drivers > BacnetNetwork** in the Nav tree.

- Double-click on the TC500 or TC300 device to open the configuration Wizard.



Fig. 6 TC500A Thermostat Configuration Wizard



NOTE:

To avoid the **[web.reporting.csp]** error in the application director output, navigate to **Services > WebService > HttpHeadersProviders > Content-SecurityPolicy** and configure the font-src property with the following text **'self' workbench data:**




Fig. 7 Avoiding [web.reporting.csp] Error

Applicable Technical Literature

Table 2 Technical Literature

Document Name	Document Number
TC Thermostat Configuration Wizard User Guide	31-00490
TC500 Thermostat BACnet Integration Guide	31-00478
TC300 Thermostat BACnet Integration Guide	31-00646

The material in this document is for information purposes only. The content and the product described are subject to change without notice. Honeywell makes no representations or warranties with respect to this document. In no event shall Honeywell be liable for technical or editorial omissions or mistakes in this document, nor shall it be liable for any damages, direct or incidental, arising out of or related to the use of this document. No part of this document may be reproduced in any form or by any means without prior written permission from Honeywell.

Honeywell Building Technologies

715 Peachtree Street, N.E.,
Atlanta, Georgia, 30308,
United States.
buildings.honeywell.com

® U.S. Registered Trademark
©2024 Honeywell International Inc.
31-00489-02 | Rev. 12-24

