


Flip-S

in desk power module

USER

MANUAL

Thank you for purchasing ABL's Flip-S power module. Flip-S has been manufactured and tested in accordance with relevant standards (see contact page).



INSTALLATION:

Note: Before making a cut-out, please contact your supplier to provide you with a technical drawing with the required table cut-out dimensions. Ensure that there is a sufficient clearance, 150mm below surface and 30mm between the cut-out edge of the work surface

Step 1.

Lift the clips and slide the side fixings down.



Step 2.

Place the module into the table cut-out.



Step 3.

Put the sliding fixings back up until the module is tightened to the table.



MAIN FEATURES:

- The Aluminium lid and modular parts are available in Black, White and Grey
- Completely configurable, available in variations of sockets, USB charge sockets, and media connections
- Rated voltage of Flip-S power module unit is 250V AC (C, E, F, G, J, L), for **B type sockets** 120V AC
- Nominal intensity of the unit:
 - 13A for **G type socket**
 - 16A for **B, C, E, F, J, L type sockets**
- G type sockets are individually fused with 3.15A or 5A fuse. Available in up to four sockets with 5A fuse, and in up to six sockets with 3.15A to comply with BS6396
- Fit desk thickness between 10 and 40 mm
- All standard options come with 0.5m drop lead to 3 Pole Connector. Cable type: H05VV-F 3x1.5 mm²
- Switch is available only with G socket type.

*The most common socket types:



Please contact us for more information

SAFETY NOTES:

- Items such as Vacuum Cleaners, Kettles, Coffee Makers, and Fan Heaters should not be connected via these power modules
- Installation is to be carried out by a qualified professional





CONTENTS:

- Flip-S power module



Complies with BS 5733 (UK)
IEC 60884-1 and IEC 60884-2-7 (Europe)



Manufacturing in-house within central
Europe under strict compliance with
ISO 9001:2015

WARRANTY CONDITIONS:

ABL warrants this product as free of defects in material, design, and workmanship for the period of twenty-four (24) months from the original date of receipt of the product, unless applicable national laws stipulate otherwise. If during the period of warranty this product proves defective under normal use and service you should return the product to the retailer from whom it was originally purchased. The liability of the ABL is limited to the cost of repair and/or replacement of the unit under warranty. The warranty is void if a failure occurs due to the following reasons:

- Improper device installation
- Improper handling
- Improper transport
- Force majeure



WARNING: Do not use this product for any other purpose other than which it was designed for.

CONTACT US

UK DISTRIBUTION CENTRE

Unit A4 Brooklands
Technology Park,
Wellingborough Road,
Syrwell, Northamptonshire,
NN4 0BA, United Kingdom
United Kingdom

+44 (0) 1933 400 080
www.abl-ftd.com

EMEA DISTRIBUTION CENTRE

Ulica Todorica 23
22100, Cacak
Serbia

+381 (0) 32 420 100
www.abl-ftd.com

MAINTENANCE:

Do not open, disassemble, change, or modify the device. Every unauthorized opening or repairing of the device leads to loss of warranty. During device usage, you need to follow basic safety measures, since safety requirements vary, please check with local laws.

