




S11 Instrument Screen`s User Instruction manual

Control Methods

1.Touch screen



Swipe and tap to control on-screen functions

2. Steering wheel button control



Functions of the right button on the steering wheel:

1. Left dial: Return/Exit
2. Right dial: Enter/Confirm
3. Scroll up and down: Switch menu

Front Camera (option)

1. Turn on the front camera function:
settings--display--front camera

2.To enter the front-view camera when it is not started:
press and hold the right button of the steering wheel to the right for 3 seconds.



Airflow Outlet Adjustment



Push the paddle up, down, left, and right to adjust the air outlet position.

Shortcut key



Swipe down from the top of the screen to enter the shortcut page



Shortcut key functions



Carplay/Android Auto

Carplay



- 1, Click the Carplay icon on the main interface menu to enter the Carplay.
- 2, Turn on the smartphone's Bluetooth.
3. Find the S11 screen's Bluetooth device "TSL*****" and connect it.

Android Auto

- 1, Click the Android Auto icon on the main interface menu to enter the Android Auto .
- 2, Turn on the smartphone's Bluetooth.
3. Find the S11 screen's Bluetooth device "TSL*****" and connect it.



Airplay/ Miracast

Airplay



- 1, Turn on the smartphone's personal hotspot.
2. Go to the S11 screen's settings to click the "Wi-Fi" to connect the smartphone's hotspot.
1. Click the "Airplay" icon on the S11 screen's main interface menu.
4. Turn on the Screen Mirroring on your iPhone, and connect the "lylink" device.

Miracast



- 1, Turn on the smartphone's personal hotspot.
2. Go to the S11 screen's settings to click the "Wi-Fi" to connect the smartphone's hotspot.
3. Click the "Miracast" icon on the S11 screen's main interface menu.
4. Turn on the Screen Mirroring on your smartphone, and connect the "Miracast" device.

Settings-Wlan



Enter the settings interface, click Wlan option, turn on/off the Bluetooth and WIFI.

Carplay/ Android Auto is Bluetooth connect.

(connect the S11 screen's Bluetooth "TSL65217CAF6BE" with the smartphone)

Airplay/ Miracast is Wi-Fi connections

(connect the smartphone's hotspot with the S11 screen)

Settings-General



click "General", on the "General" interface to set more functions.

- ✧ Temperature unit switching (F/C)
- ✧ Time system switching (12Hours/24hours)
- ✧ Time zone setting (UTC)
- ✧ Speed limit sign setting. (General/ US)
- ✧ Audio output .(loudspeaker-S11`s Speaker, Bluetooth-Tesla Speaker)

Bluetooth operation method:

1.Set the Audio output to "Bluetooth" on the settings interface.

2.Connect the smartphone`s Bluetooth with Tesla`s Screen when use the Carplay/Android Auto, Airplay/Miracast/HUAWEI Hicar functions.

- ✧ Pressure unit switching, (Bar/Psi)

Settings-Model



1. Enter the Settings interface
2. Click "Model" option.
3. Choose the car model and the model's color.
4. return to the main interface.

Settings-Display



1. Enter the Settings interface
2. Click "display" option.
3. Choose the UI themes, day/night model and Auto model (follow the Tesla system), rainbow road turn on/off, full screen/half screen switch front camera turn on/off
4. return to the main interface.

Settings-Software



mcu

Canbus software update via USB driver,
Operation method:

download the software into the USB driver's root directory, insert the USB driver into our S11 screen's USB port then click this mcu button.

ota

OTA the Canbus software via WiFi,
Operation method:

connect the S11 screen's WiFi with the smartphone's hotspot. then click this "OTA" button to update to the newest version.

ota mcu

OTA the APP software via WiFi
Operation method:

connect the S11 screen's WiFi with the smartphone's hotspot. then click this "ota mcu" button to update to the newest version.

Blind Spot Monitoring



When a vehicle appears in the left and right blind spots, the left and right sides of the instrument will flash yellow light
When a vehicle appears within the blind spot, turn on the turn signal, and the left and right sides of the instrument will flash red light as a warning.

Hands-off Reminder



Real-time synchronization of FSD steering wheel hands-off reminder

Rainbow Road



Real-time synchronization of original vehicle information - Rainbow Road (can be turned off, in the settings page - Display - Rainbow Road), vehicle speed, lights, gear, tire pressure, battery, etc.