


MR-70X Part# 110-5170-30 Install directions

This cable is used on the Harris XL-185M and XL-200M transceiver or Remote head 44-pin accessory port without options cable



Radio Programming under "Audio Settings" "Master" box needs to be checked for speaker #1 on the transceiver to have output.

Under “External IO Options” set Auxiliary Input 1 to PTT using the drop-down selections.

The screenshot displays the 'W Mobile' settings application. On the left is a vertical sidebar menu with various options. The 'External IO Options' menu item is highlighted with a dark background. The main content area on the right is titled 'External IO Options' and contains three sections for 'External Output Control Line 1', 'External Output Control Line 2', and 'External Output Control Line 3'. Each section includes 'Output' and 'Mode' dropdown menus, a 'Custom Pattern 1-16' row of buttons, and a 'Repeat' checkbox. Below these sections is a 'Repeat' label and three 'Auxiliary Input' dropdown menus. The first dropdown, 'Auxiliary Input 1', is set to 'PTT' and is indicated by a large red arrow. The other two dropdowns, 'Auxiliary Input 2' and 'Auxiliary Input 3', are both set to 'No Function'.

W Mobile

- PTT Conventional Frequency (B)
- Phone Call
- Touche Frequency (Y)
- LISTS
- SETTINGS**
- Agency Data - iDACS
- Agency Data - EDWS IP
- Alert
- Audio Settings
- Bluetooth Settings
- Clock Settings
- Conventional Emergency Phone
- Custom Scale
- Data
- DHCP - Connected
- Diagnostic
- Digital Voice
- Display Settings
- DTMF
- Emergency Check for T-Event Options
- Encrypted Data Configuration
- External IO Options**
- External Speaker Options
- General
- GPS Settings
- Incident Command Options
- Key Window List
- Repeat
- Module Programmable Buttons

External IO Options

External Output Control Line 1

Output: Disabled
Mode: Disabled
Custom Pattern 1-16: [Buttons]
Repeat: [] Active: []

External Output Control Line 2

Output: Disabled
Mode: Disabled
Custom Pattern 1-16: [Buttons]
Repeat: [] Active: []

External Output Control Line 3

Output: Disabled
Mode: Disabled
Custom Pattern 1-16: [Buttons]
Repeat: [] Active: []

Repeat

Auxiliary Input 1: PTT
Auxiliary Input 2: No Function
Auxiliary Input 3: No Function