

RCW1
User Manual


INTRODUCTION

Charge smarter and faster with the 50W Retractable Dual Wall Charger, featuring a compact design with retractable prongs for ultimate portability. Equipped with a Type-C Power Delivery (PD) port and a QC 3.0 USB-A port, this charger delivers up to 50W of power to charge your devices at lightning speed. Perfect for smartphones, tablets, laptops, and other USB-powered devices, it allows simultaneous charging without compromising efficiency. Whether at home, in the office, or on the go, this ETL-approved charger ensures reliable, safe, and super-fast power for all your devices.

SPECS & FEATURES

- 50 Watts
- ETL Approved
- Retractable Type-C Charging Cable
- Dual Charging Ports
- PD Type-C Port + QC 3.0 USB Port
- Overload / Overheat Protection

PRODUCT OVERVIEW



HOW TO USE

Unbox and Inspect the Charger

Remove the charger from its packaging and ensure there are no visible signs of damage.

Familiarize yourself with the two ports: Type-C Port: For Power Delivery (PD) fast charging. QC 3.0 USB-A Port: For Quick Charge-compatible devices or universal charging.

Plug in the Charger: Slide out the retractable prongs by gently pulling them from the back of the charger. Insert the prongs into a standard AC wall outlet (100V–240V). Ensure the charger is securely plugged in.

Connect Your Devices

Using the Type-C Port: Use a USB-C to USB-C cable or USB-C to Lightning cable (for Apple devices). Plug one end of the cable into the Type-C port and the other into your device.

Using the QC 3.0 USB-A Port: Use a compatible USB-A to device cable. Plug one end of the cable into the USB-A port and the other into your device.

Simultaneous Charging: Connect one device to the Type-C port and another to the QC 3.0 USB-A port. The charger will distribute power intelligently, providing fast charging to both devices (up to 50W total).

Confirm Charging: Check your device's screen or charging indicator to ensure it is charging correctly. For fast charging, ensure your device is compatible with PD (Type-C) or QC 3.0 (USB-A).

Retract the Prongs After Use

Once your devices are fully charged, unplug the cables from the charger. Remove the charger from the outlet. Gently push the prongs back into the charger for compact storage.

CARE AND SAFETY

Disconnect your device from the cable once fully charged. Remove the wall charger from the outlet if it is not in use to conserve energy. Do not overload the outlet or use extension cords that are not rated for high power devices. Ensure the charger has sufficient airflow and is not covered while in use. Disconnect the charger immediately if it becomes excessively hot during operation.

PACKAGE INCLUDES

4'ft Type-C to C cable + MFI Adapter
Wall Charger