


EKET



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.



NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.






10093081

12x




10093082

12x




152650

2x




152651

2x




141413

2x



141414







2x




AA-1908823

1x


1




2




3




4




5




6




7







8





9










11





12







13








14




15









16





17






AA-1908823



AA-1908823



AA-1908823

