





Diagrams

BOTTOM



TOP



Getting Started

Before using your pureAir 501 you will need to find the area (or square footage) of the environment. To do this accurately, take into account all connected rooms with open doorways **(the purification does not flow through closed doors)**. The pureAir 501 can purify up to 850 square feet of space **(based upon an open floor plan with 8.5' ceilings)**.

1. Plug the *Power Adapter* into a wall outlet and then plug the other end into *Power Port* of your unit.
2. Press the *Power Button* once to turn your unit *ON*. The unit begins in *Ionization Mode (Green Light)*. Press it again to change to *Purification Mode (Blue Light - Ozone)*. Press it one more time to turn the unit *OFF*.
3. Press the *Away Mode Button* on the top of your unit to activate the *Away Mode (Red Light)*.



DO NOT use AWAY MODE in spaces occupied by human beings or pets. Allow for 2 hours following treatment in AWAY MODE prior to re-entering. Temporary adverse reactions such as throat irritation, coughing, chest pain, or shortness of breath may be caused by excessive levels of ozone. If irritation occurs, check that unit is turned off and further ventilate space prior to returning. If adverse reaction persists, seek medical attention and discontinue use of device.

NOTE: Your unit will revert back to its previous mode after the 30 minute cleaning cycle has ended. Away Mode can also be activated while the unit is OFF. Once complete, your unit will shut OFF.

NOTE: Once your unit is turned OFF, it will continue to operate for 30 seconds to clear any ozone remaining inside.