




User's Guide



DIGIRUSS


NO. MZY20 081107—02

MODEL:
DHP12BA
DHP15BA
DHP18BA

Standards : SJ/T 10406-93
1Please keep the user's manual!

Use the product carefully before you read the instructions

Function Indication



- 1 .Power input socket
2. Power switch
3. Volume control
4. Low-pass frequency adjustment
5. phase adjustment
- 6 .LED indicator light
7. XLR/RCA input jack
- 8 .Low cut/by pass key
9. Hig cut/by pass key

Parameter	DHP12BA	DHP15BA	DHP18BA
Тип системы	Активная низкочастотная акустическая система		
Разъёмы:	XLR F (input), XLR M (link), Powercon (type A).		
Компоненты:	<u>1*12 inch</u>	<u>1*15 inch</u>	<u>1*18 inch</u>
Встр..усилит./мощн. :	<u>400 Вт</u>	<u>500 Вт</u>	<u>700 Вт</u>
Вес	<u>32 кг.</u>	<u>43 кг.</u>	<u>47 кг.</u>
Частотный диапазон	<u>45Гц-200Гц</u>	<u>43Гц-200 Гц</u>	<u>40Гц-200Гц</u>
Корпус	<u>Фанера</u>	<u>Фанера</u>	<u>Фанера</u>
Max SPL	<u>121 дБ</u>	<u>123 дБ</u>	<u>127 дБ</u>
Размер(ВХШхГ)	<u>600X460X500</u>	<u>660X520X560</u>	<u>780"520"560</u>

