## Mobile Phone with the Same Screen

the "Settings" interface of the phone.

3. Open "Eshare".

4. Open "Airplay" / "Screen Mirror". 5. Find the projector and click.

## Mobile Phone Projection

### How to "push" contents to the projector

1. Ensure the Phone and Projector are under the same WIFI.

push icon design).

\* Note: Not all video software have function of push.

3. Click this icon to push videos to the projector. At the same time, we can have other.





Shenzhen Wanbo Technology Co., Ltd.

How to be with the same screen for iPhone under status of No Wifi 1. If there has no WIFI, firstly open 4G network of iPhone, then open WIFI hot spot in

2. Collect iPhone's hot spot WIFI for the projector.

\* Note: Advantage of push is it does not affect normal use of the mobile phone.

2. Open video software of the mobile phone and finds the TV push icon in the four corners (it's usually on the top right or on the bottom right) (Each APPs have different

operations on the phone, it will have no conflict.





Schematic diagram of some push icons

# FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the

following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment doescause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by o ne or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the

receiver is connected. —Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).

The device has been evaluated to meet general RF exposure requirement.

## Projection Distance Reference

Projection size (under status of no keystone correction / Inch)	Screen length * width (cm)	Lens ~ screen (m)
55	122 × 68	1.49
60	133 × 74	1.63
70	155 × 87	1.9
80	177 × 100	2.17
90	199 × 112	2.44
100	221 × 125	2.71
110	244 × 137	2.98
120	266 × 149	3.25

Note: Projection size and distance are calculated according to projection ratio, which may have a deviation and subject to actual status.

## Singal Source Setting

Enter Setting interface in the main screen and select input source. Enter into AV/HDMI signal channel, Press "OK" " to switch input source.

If you want to return to the previous layer, please press the return key; If you want to return to the main interface, please press the main screen key.

## Cleaning Method

Please make sure the power plug is unplugged before cleaning. Do not use pesticides or other volatile chemicals on the projector or lens. Do not let rubber or vinyl products contacts the projector for a long time, which will damage the

coating and make it peeled off.

that stuck with diluted neutral detergent, then dry with a clean and dry cloth. Please pay more attention if used with chemical fiber cloth. 2. Don't use thinner, benzene or any other solvents to avoid quality reduction or coating

peeling off etc. 3. A brush can be inserted into the front of the vacuum cleaner to remove dirt inside the vents. Please don't use vacuum cleaner with no connector, or clean with vents directly.

4. Please don't scrape the machine with nails or any other hard objects so as to avoid

1. Wipe with a soft, dry cotton cloth. If it's dirtied seriously, we can wipe with soft cloth

· Lens Cleaning

1. Clean lens with the same method for camera lens: please use professional blow dryer or cleaning paper for glasses, ensure lens are not scratched.

Inlet and Outlet Dust Cleaning

2. Disconnect power line after turn off the projector.

1. Dust in the inlet and outlet will prevent ventilation and increase the internal temperature, which will cause defect.

3. Clean the exterior with an electric vacuum cleaner, please install brush head adapter on the vacuum cleaner first. Kindly take note: don't use vacuum cleaner with no

## Poisonous and Harmful Substance, Element Name and Content

	Hazardous substances					
Part name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybro minated Biphenyls (PBB)	Polybro minated Diphenyl Ethers (PBDE)
Shell	0	0	0	0	0	0
Optical Machine	0	0	0	0	0	0
Circuit Board	0	0	0	0	0	0
Fan	0	0	0	0	0	0
Other Wires	X	0	0	0	0	0
Remote Control	0	0	0	0	0	0
Power Supply	0	0	0	0	0	0

O: Content of the hazardous substance in all homogeneous materials of the component is under the limits of SJ/T11363-2006.

X: Content of the hazardous substance exceeds the limit requirements specified by SJ/T11363-2006 in at least one homogeneous material of the component. The components labeled "X" " have no substitutive due to global technology development limits. Circuit board assembly \*: including printed circuit board and its components, electronic components, etc.

The number in the logo represents the normal environmental service life of the product. (Battery Excluded)

## Warranty Card

- 1. We offer "three guarantees " for this product, One year warranty for nonartificial damaged since purchasing (subject to purchase record).
- 2. We will provide warranty service for any default caused by product technical reasons during warranty period.
- 3. Following situations are out of the range of guarantee: 1 Accessories out of the mainframe
- ② Unauthorized disassembly and repair without our consent.
- ③ Damage that caused by external force and other natural disasters. 4. Please fill this card and contact your distributor when products have quality
- 5. This warranty is limited to product maintenance during the warranty period, no other liability



# wanbo

WPB84



# Wanbo Projector Mozart 1 (Introduction Manual)

Before using this product, please read this product manual carefully

Thank you for purchasing our products. For your safety and benefit, please read this product manual carefully before using. If you fail to follow the product instructions or precautions, and cause any personal injury, property or other losses, the company will not bear any responsibility.

## Important Safety Precautions

## You are recommended to use the projector in a dark room to achieve the best effect.

- 1. Please don't install in places that directly blown by cold and warm air of air-conditioning, water condensation or high temperature may lead to failure to the machine.
- 2. Ensure adequate ventilation and vent are not blocked to prevent heat accumulation 3. Please prevent foreign matters such as nails or paper scraps from falling into the

machine. Do not insert any metals such as iron wire or screwdriver into the machine.

Please turn off the power immediately and turn to professional technician to remove

to protect the lens from scraping, in addition, keep the projector from violent vibration.

- it if any foreign matters fall into the body.
- 4. Do not place any liquid on this machine to avoid risk of electric leakage. 5. Please use soft packaging materials to move the projector, install lens protection cover
- 6. Areas near the exhaust will become hot during and after we use the projector, it may lead to scald if we touch with hand. 7. Please don't watch lens directly when it's on so as to protect our eyes from damage.

# ✓! Note:

· Don't open the shell to prevent electric shock, Please turn to qualified professional maintenance personnel for the maintenance as there are no parts in the machine that users can repair themselves.

· Don't expose the machine to rain or moisture so as to prevent misfire or electric shock.  $\cdot$  The product is applicable to be used under a temperature of 0-35  $^{\circ}$  for a safe side.

# Important Safety Precautions




















Don't install in dusty and smoky areas






## Projector Part Name and Function







# \*Please check whether the connection is correct according to the mark on the power cord.

# Installation and Adjustment





Short press the power button or the "" " key on the remote control, once shutdown prompt box appears, short press the power button or the power key on the remote control again.



Schematic diagram of blurred image

# Projector hanger installation steps

Remove the 4 pads Adjust hanger angle to align with the hole and then tighten screws





Fixed the hanger

# **Basic Parameters**

Product Name	Wanbo Projector	Display Principle	LCD
Light Source	LED	Horn	8W*2
Operation Mode	Remote Control	Working Environment	0-35 ° C
Output Port	Headphone Audio Output	Input Port	HDMI/USB
Net Weight	3.5 kg	Machine Size	209*176*223mm
Accessory	User Manual / RemoteControl / Power Cord		


# Remote Control





# Mobile Phone with the Same Screen

The following steps can help us to display content of our mobile phone to projection screen synchronously through wireless wifi, just enjoy with a larger picture (Applicable for intelligent Android version only).



- 1. Ensure the Phone and Projector are under the same WIFI (For Android Only).
- 3. Choose the device with the same name with Eshare to complete mirror.

# 1. Ensure the Phone and Projector are under the same WIFI (For IOS Only).

Mobile Phone with the Same Screen

2. Open"Eshare" of the projector. 3. Open "AirPlay"/ "Mirror" of the Phone.

IOS Devices User Instruction



# U Disk Support Format

File Type File format supported	
Picture	JPG/PNG/BMP
Video	AVI,DAT,FLV,MKV,MOV,MPG,MPEG,MP4,RM,RMVB,SWF, 3GP,TS,VOB
Audio	AMR,FLAC,M4A,MP3,MP2,OGG,WAV

Note: Specific operation contents are subject to actual situation due to irregular update of the product system.