# Designed to Enhance

## **60cm Ceramic Cooktop** OCC604TZ

### <u>o</u>mega


Quick Start Guide OCC604TZ

#### Introducing your new

#### **60cm Ceramic Cooktop**

#### Cooktop Overview

A. Cooktop Controls B. Ø190mm Zone × 2 C. Ø155mm Zone × 2



#### **Cut-Out Diagram**

For minimum distance requirements and safety advice, please refer to your supplied User Manual, pages 04–08.



#### Details

Product Dimensions (W, D, H):  $590 \times 520 \times 50$ mm Cut-Out (W, D):  $560 \times 490$ mm | Warranty: 3 Years

#### Cooktop Controls

Zone Selection

Used to select and monitor which zones you would like to cook with.

Adjustment Controls

Each button increases or decreases the selected zone's temperature setting.

Timer Function

A kitchen timer and a way to automatically shut off zones after a set period of time.

Child Safety Lock

Disables cooktop controls to prevent use, such as accidental activation by children.

Power Button

This button is used to easily power the cooktop both on and off.

For a detailed guide on operating your Omega cooktop, please refer to your supplied User Manual, pages 17–26.

#### Support

Telephone: 1300 11 HELP (4357) Email: support@residentiagroup.com.au

