



Originale	Sostituto
 Power	 Power
 My Media/USB	 Media
 Input	 AV
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 <<	 <<
 >>	 >>
 Mark	 Guide
 Keys Up	 1
 Keys Down	 4
 Sleep	 Sleep
 Picture	 Format
 3D	 3D
 L/R	 Pre Ch
 Vol+	 Vol +
 Vol-	 Vol -

Originale	Sostituto
 Page Up	 Ch +
 Page Down	 Ch -
 Ratio	 TV/R
 Blank	 Text
 Mute	 Mute
 Settings	 Options
 Still	 Smart
 Q.Menu	 Menu
 Back	 Back
 Auto	 Eject
 Exit	 Exit
 OK	 Ok
 UP	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red



