



VIHALS



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:




ALWAYS install anti-tip device provided.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

ALWAYS secure your television with an anchor device.

English

Read and follow each step of the instruction carefully.






4x




12x




4x




4x




12x




12x




8x



8x




2x




1x

A




145718
159553
1009669

8x



130449

8x




119030
117434
131361

16x




146114

12x




10071494
10099810
10106969

2x




10040242

2x





23




10060247
10103384
10107145


2x




1




2




3




4




5




6





7




8




9




10




11



12





13







14

10x







15

4x




16







17




18





X

X






www.IKEA.com/secure-it




www.IKEA.cn/secure-it



English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


A




Ø 8 mm
(5/16")




1




2



3




B




Ø 8 mm
(5/16")




1




2



3




C




Ø 3 mm
(1/8")




1








2








20







20





21





22







23




24




25




26




27




28






29




30







32



33



34



35

