



F800 **TRIO**

3-CHANNEL DASH CAM

USER MANUAL



**REGISTER
WARRANTY**

Warm Tips:
Please scan the code or visit below link to register
your 12-month warranty for free in first 30days.

CUSTOMER SUPPORT

- ▶ Item NOT As Describe?
- ▶ Item Damage or Defective?
- ▶ Missing Items or accessories?
- ▶ Problem with installation?
- ▶ Any issues what so ever.....

CONTACT US BEFORE RETURNING THE ITEM
WE WILL HELP YOU SOLVE ANY ISSUES

EMAIL US:

Email to us directly by scanning the QR code.

help@catveer.com

Usually response in 8hours

Message/Call US:

Message or Call us directly by scanning the QR code.



2.Register Warranty

G900 dash cam is coming with 1-year warranty.

Please kindly register the warranty with your AMAZON **Order #** by:

- Scan the QR code to register on your phone



- Or enter the web and register on the PC:

<https://www.gmaipop.com/col.jsp?id=115>

GET BENEFITS FROM WARRANTY

- *30-day money-back guarantee for any reason*
- *12-month warranty for quality-related issues*
- *Free user technical support*
- *Firmware version update*
- *New release promotion*

INDEX

1. Important Tips.....	05
2. Box Contents.....	07
3. Dash Cam Overview&Buttons.....	08
4. Power on(Start Recording).....	11
5. Power Off (Stop Recording).....	12
6. Settings.....	13
<i>6.1 Enter/Exit Setting</i>	13
<i>6.2 Setting Contents</i>	14
7. How to use WiFi&APP.....	17
8. Playback the recorded video.....	22
9. Installation.....	26
<i>9.1 Install Front Camera</i>	27
<i>9.2 Install the External Camera</i>	34
10. Important Functions.....	40
<i>G-sensor&Loop Recording</i>	40
<i>Time-lapse Video&HDR&Take Photos</i>	41
11. FAQ(Frequent asked questions).....	42
12. Warranty and After-Sales.....	44
13. Thanks for your Purchasing.....	45

1. Important Tips

Please read and understand warnings & safety instructions before operating

a. insert SD card

- 64GB SD Card is inserted in the dash cam already.
- The SD card can only be inserted from one direction. Before insert it, Please make sure the direction is correct as the figure photo.



IMPORTANT NOTES

b. Time Lapse video Mode and **24H Park Monitor** will be triggered only when the Hardwired Kit is connected.



GMAIPOP Hardwire Kit:
ASIN: **B0CC9JXNVD**

c. Turn on WiFi Quickly

Step ① Press  stop recording

Step ② Long Press on  to turn on WiFi

d. Battery & Charger

- The dash cam batter(200mAh)is just to maintain and save settings. It should be connected to the car charger or USB to get constantly powered, if the power is interrupted to the unit, it will shut down.
- Please use the original car charger provided to avoid fault or incompatibility.







e. Cautions for High Temperature

- Don't leave this product where the temperature may exceed 70°C (160°F)for an extended period.
- When using a sunshade, please do not place the dash cam between the windshield and sunshade, it may cause damage from heat buildup

f. Getting a rear camera cable extension

If the length(19.7feet) of the rear camera cable is too short for your car,please get a GMAIPOP extension cable by ASIN:**BOCH84SXZP**

2.Box Contents

 +	<p><i>DashCam F800 & 64GB SD Card</i></p>	<p>The SD card is inserted in the dash cam already.Please format SD card regularly when G-sensor is on.</p>
 +	<p>Suction Mount <i>3M Sticky Mount</i></p>	<p>Choose the bracket preferred and install it according to Page 30-31</p>
	<p><i>USB-C Car Charger</i></p>	<p>Input:12-24V Output:5V/2A Please use the GMAIPOP original charger for G900</p>
 +	<p><i>1080P External Camera & 19.7ft connection cable</i></p>	<p>Using the 19.7ft connection cable to install the external camera in the rear windshield glass according to Page 37</p>
	<p><i>Accessories Bag</i></p>	<ul style="list-style-type: none"> * Cable Hiding Clip * Electrostatic film * Install kit * Replacement adhesive * Wet&Dry Wips
 +	<p><i>Manual & Warranty Card</i></p>	<p>Please register the warranty and read manual carefully</p>

3.Dash Cam Overview&Buttons



Multiple Function Buttons



In different status, the button have different functions, pleasee kindly refer to the button icon on the screen

In Recording Status

Recording Indicator Light

Blue.

When recording, the light is flashing. When NON-Recording, the light is always on and non-falsh.



①

②

③

④

① Emergency Recording

③ Take Photo

② Mute/Unmute Audio


④ Stop Recording

In NON-Recording Status

Charging Indicator Light

Red.

When charging for battery, the light is on. When battery is full charged, the light is of.



⑤

⑥

⑦

⑧

⑤ **Short Press** to enter Set
Long press to turn on WiFi

⑦ Switch the front/rear display window

⑥ Enter File Management

⑧ Start Recording

In Set Status




① Exit Set

② Scrop UP

③ Scrop DOWN

④ OK

In Filemangement Status



⑤ **Exit Filemangement**

⑥ Scrop to UP


⑦ Srop DOWN

⑧ OK

4.Power On(Start Recording)

The dash cam will automatically start recording when the car is powered on.

Engine the car, the dash cam will start and record automatically. The Recording icon will flash as “●”(Red).



- ① **Recording Icon** Red Icon in normal recording
Yellow Icon means the emergency recording and video recorded will be locked

- ② Resolution icon
③ Lock/Ulock
④ Mute Recording
⑤ Take Photo

- ⑥ Stop Recording
⑦ Battery/Charger Status
⑧ WiFi icon
⑨ Audio icon

If the dash cam doesn't start and record automatically, Please kindly go through the steps below:

- a. Make sure car charger connection is correct***
- b. Whether SD card is full, if yes, please format***

If there are still problems after checking, please contact us for replace/refund.

5.Power Off (Stop Recording)


a.Stop recording and turns off automatically:

When Car is Off, the dash cam will stop recording and turns off automatically.

Some car cigarette lighters will delay to power off when the engine is off, then the dash cam will delay off automatically as well.


b.Stop recording manually:

When Car is Off, the dash cam will stop recording and turns off automatically.



6. Setting

6.1 Enter/Exit Set




Step ①

Press  button stop recording







Step ②

Short Press  button enter Set



Step ③

- Press  to scroll to **UP**.
- Press  to scroll to **DOWN**.
- Press  to **EXIT**.
- Press  to **CONFIRM**.

6.2 Settings Contents

Setting Name	Setting Options	Instruction
Resolution	4K(Default)	Choose the video resolution you like. Higher resolution videos will take more storage space.
	2K	
WiFi&APP	Off(Default)	Enter to turn on the Camera's WiFi and Scran the QR code to dowload the APP.
	On	

(Refer to more settings in next page.....)

Format	Off(Default)	Format SD card. If G-sensor is on, please format the SD card regularly
	On	
Help	Find our 24H Customer Service here	
Looop Record	1MIN(Default)	Set Loop recroding time, the video will be saved in increments (Details in Page 24)
	3MIN	
	5MIN	
HDR	On(Default)	Improves the exposure by taking the combinations of over exposed and under exposed image into one robust wide range of lighting with higher depth image
	Off	
G-Sensor	Off(Default)	Setting G-Sensor's sensitivity level.(Details in Page 41)
	Low	
	Medium	
	High	
Time-Lapse	Off(Default)	It will be triggered only when the Hardwired Kit is connected. (Details in Page 42)
	1s	
	2s	
	3s	
24H Parking Monitor	Off(Default)	Turn on/off the Parking Guard
	On	
Screen Auto Sleep	Off(Default)	Over the set time and no operation, the display screen will automatically turn off. If you want turn on,press any button
	1Min	
	3Min	
	5Min	

(Refer to more settings in next page.....)

Volume	Mute	Setting the Volume of the camera
	Low	
	Middle(Default)	
	High	
Date/Time	Setting the date&time.	
Buttnon Sound	Off	Turn on/ff the button sound
	On(Default)	
Boot Sound	Off	Turn on/ff the operation sound when camera is on&off
	On(Default)	
Date Stamp	Off	Turn on/off the date display in videos
	On(Default)	
Fliping RearCam Image(Up&Down)	Off(Default)	Fliping the rearcam's image up&down.It helps to filp the image when installing the external cam in wrong direction
	On	
Plate NO.	Off(Default)	Turn on/off displaying the car plate NO. in the recorded video
	On	
Audio Recording	Off(Default)	Turn on/off the audio recording when recording video
	On	
Language	English(Default)	Select Language for dash cam
	Spanish etc..	
Restore Settings	Cancel	Restore All the Settings
	Cofirm	

7.How to Use WiFi&APPs



How to Using WiFi


Please kindly scan the QR code to view video guidance of using WiFi.

Or search the web address on PC

<https://youtu.be/l44bJPuLUFw>

Step 1. Download APP:

Please Search in Google Play or Apple Store for free APP **"Viidure"** to download APP




Or Scran the QR code to download



Viidure

Step 2. Turn on the F800's WiFi:


Method 1: Stop Recording Firstly, Long Press on the  button.



Step ①
Press  button stop recording



Step ②
2-3s **Long** Press  button enter Set



EXIT