## CATVEER





## **USER MANUAL**



Warm Tips:

Please scan the code or visit below link to register your 12-month warranty for free in first 30days.

## CUSTOMER SUPPORT

- ▶ Item NOT As Describe?
- ▶ Item Damage or Defective?
- ► Missing Items or accessories?
- ▶ Problem with installation?
- ▶ Any issues what so ever......

# CONTACT US BEFORE RETURNING THE ITEM WE WILL HELP YOU SOLVE ANY ISSUES

#### **EMAIL US**:

Email to us directly by scanning the QR code.

## help@catveer.com

Usually response in 8hours

#### Message/Call US:

Message or Call us directly by scanning the QR code.





#### 2. Register Warranty

G900 dash cam is coming with 1-year warranty.

Please kindly register the warranty with your AMAZON **Order #** by:

- Scan the QR code to register on your phone



- Or enter the web and register on the PC:

https://www.gmaipop.com/col.jsp?id=115

#### **GET BENEFITS FROM WARRANTY**

- 30-day money-back guarantee for any reason
- 12-month warranty for quality-related issues
- Free user technical support
- Firmware version update
- New release promotion

## INDEX

| 1. Important Tips  | 05                                     |
|--|--|
| 2. Box Contents  | 07                                     |
| 3. Dash Cam Overview&Buttons   | 80                                     |
| 4. Power on(Start Recording)   | 11                                     |
| 5. Power Off (Stop Recording)  | 12                                     |
| 6. Settings 6.1 Enter/Exit Setting 6.2 Setting Contents  | 13<br>13<br>14                         |
| 7. How to use WiFi&APP   | 17                                     |
|  |  |
| 8. Playback the recorded video   | 22                                     |
| 8. Playback the recorded video  9. Installation  9.1 Install Front Camera  9.2 Install the External Camera   | 26<br>27                               |
| 9. Installation 9.1 Install Front Camera   | 26<br>27<br>34<br>40<br>40             |
| 9. Installation 9.1 Install Front Camera 9.2 Install the External Camera 10. Important Functions G-sensor&Loop Recording                                   | 26<br>27<br>34<br>40<br>40<br>41       |
| 9. Installation 9.1 Install Front Camera 9.2 Install the External Camera  10. Important Functions G-sensor&Loop Recording Time-lapse Video&HDR&Take Photos | 26<br>27<br>34<br>40<br>40<br>41<br>42 |

#### 1. Important Tips

Please read and understand warnings & safety instructions before operating

#### a. insert SD card

- 64GB SD Card is inserted in the dash cam already.
- The SD card can only be inserted from one direction.
   Before insert it, Please make sure the direction is correct as the figure photo.



#### **IMPORTANT NOTES**

b. Time Lapse video Mode and 24H Park Monitor will be triggered only when the Hardwired Kit is connected.



GMAIPOP Hardwire Kit: ASIN: *BOCC9JXNVD* 

#### c. Turn on WiFi Quickly

Step 1 Press stop recording

Step ② Long Press on @/ to turn on WiFi

#### d. Battery & Charger

- The dash cam batter(200mAh)is just to maintain and save settings. It should be connected to the car charger or USB to get constantly powered, if the power is interrupted to the unit, it will shut down.
- Please use the original car charger provided to avoid fault or incompatibility.

#### e. Cautions for High Temperature

- Don't leave this product where the temperature may exceed 70°C (160"F) for an extended period.
- When using a sunshade, please do not place the dash cam between the windshield and sunshade, it may cause damage from heat buildup

#### f. Getting a rear camera cable extension

If the length(19.7feet) of the rear camera cable is too short for your car, please get a GMAIPOP extension cable by ASIN: **BOCH84SXZP** 


## **2.Box Contents**

| +     | DashCam F800<br>&<br>64GB SD Card                     | The SD card is inserted in the dash cam already. Please format SD card regularly when G-sensor is on.                            |
|-------|---|--|
| +     | Suction Mount  3M Sticky Mount                        | Choose the bracket preferred and install it according to <b>Page 30-31</b>   |
|       | USB-C Car Charger                                     | Input:12-24V Output:5V/2A Please use the GMAIPOP original charger for G900   |
| +     | 1080P External Camera<br>&<br>19.7ft connection cable | Using the 19.7ft connection cable to install the external camera in the <i>rear windshield</i> glass according to <i>Page 37</i> |
| 1 2   | Accessories Bag                                       | * Cable Hiding Clip<br>* Electrostatic film<br>* Install kit<br>* Replacement adhesive<br>* Wet&Dry Wips                         |
| + 200 | Manual<br>&<br>Warranty Card                          | Please <i>register the warranty</i> and read manual carfully   |

#### 3.Dash Cam Overview&Buttons







In different status, the button have different functions, pleasae kindly refer to the button icon on the screen

#### **In Recording Status**

## **Recording Indicator Light** Blue.

When recording, the light is flashing. When NON-Recording, the light is always on and non-falsh.



- 1 Emergency Recording
- (2) Mute/Unmute Audio

- 3 Take Photo
- (4) Stop Recording

#### **In NON-Recording Status**

## **Charging Indicator Light** Red.

When charging for battery, the light is on. When battery is full charged, the light is of.



- (5) Short Press to enter Set Long press to turn on WiFi
- Switch the front/rear display window
- (6) Enter File Management
- 8 Start Recording

#### **In Set Status**



- 1 Exit Set
- 2 Scrop UP

- 3 Scrop DOWN
- (4) OK

### **In Filemanagement Status**



- (5) Exit Filemangement
- 7 Srop DOWN


6 Scrop to UP

8 OK

#### 4. Power On(Start Recording)

The dash cam will automatically start recording when the car is powered on.

Engine the car, the dash cam will start and record automatically. The Recording icon will flash as "•" (Red).



- 1 Recording Icon Red Icon in normal recording Yellow Icon means the emergency recording and video recorded will be locked
- (2) Resolution icon
- 3 Lock/Ulock
- 4 Mute Recording
- (5) Take Photo

- 6 Stop Recording
- (7) Battery/Charger Status
- (8) WiFi icon
- 9 Audio icon

If the dash cam doesn't start and record automatically, Please kindly go through the steps below:

- a. Make sure car charger connection is correct
- b. Whether SD card is full, if yes, please format

If there are still problems after checking, please contact us for replace/refund.

#### **5.Power Off (Stop Recording)**

#### a. Stop recording and turns off automatically:

When Car is Off, the dash cam will stop recording and turns off automatically.

Some car cigarette lighters will delay to power off when the engine is off, then the dash cam will delay off automatically as well.

#### b.Stop recording manually:

When Car is Off, the dash cam will stop recording and turns off automatically.



## 6. Setting

## 6.1 Enter/Exit Set







### Step ③

- Press to scroll to UP.
- Press to scroll to DOWN.
- Press to EXIT.
- Press on to CONFIRM.

### 6.2 Settings Contents

| Setting Name | Setting Options | Instruction   |
|--------------|-----------------|---|
| Resolution   | 4K(Default)     | Choose the video resolution you like.  Higher resolution videos will take |
|              | 2K              | more storage space.   |
| WiFi&APP     | Off(Default)    | Enter to turn on the Camera's<br>WiFi and Scran the QR                    |
|              | On              | code to dowload the APP.  |

(Refer to more settings in next page.....)

| Farmant           | Off(Default)                       | Format SD card. If G-sensor is on,   |  |
|-------------------|------------------------------------|--|--|
| Format            | On                                 | please format the SD card regularly  |  |
| Help              | Find our 24H Customer Service here |  |  |
| Lagan             | 1MIN <i>(Default)</i>              | Set Loop recroding time, the   |  |
| Looop<br>Record   | 3MIN                               | video will be saved in increments  |  |
|                   | 5MIN                               | (Details in Page 24)   |  |
| HDR               | On <b>(Default)</b>                | Improves the exposure by taking the combinations of over exposed and               |  |
|                   | Off                                | under exposed image into one robust wide range of lighting with higher depth image |  |
|                   | Off(Default)                       |  |  |
| G-Sensor          | Low                                | Setting G-Sensor's sensitivity   |  |
| G-Serisor         | Medium                             | level.(Details in Page 41)   |  |
|                   | High                               |  |  |
|                   | Off(Default)                       | It will be triggered only when   |  |
| Time-Lapse        | 1s                                 | It will be triggered only when the Hardwired Kit is                                |  |
| Time Eapoo        | 2s                                 | connected.   |  |
|                   | 3s                                 | (Details in Page 42)   |  |
| 24H Parking       | Off(Default)                       | Turn on/off the Parking Guard  |  |
| Monitor           | On                                 | rum on/on the ranking Guard  |  |
|                   | Off(Default)                       | Over the set time and no   |  |
| Screen Auto Sleep | 1Min                               | operation, the display screen will automatically turn off.                         |  |
|                   | 3Min                               | If you want turn on,press  |  |
|                   | 5Min                               | any button   |  |

(Refer to more settings in next page.....)

|                    | Mute                   |  |  |
|--------------------|------------------------|--|--|
| Volume             | Low                    | Sotting the Volume of the comore                               |  |
|                    | Middle(Default)        | Setting the Volume of the camera                               |  |
|                    | High                   |  |  |
| Date/Time          | Setting the date&time. |  |  |
| Buttnon Sound      | Off                    | Turn on/ff the button sound                                    |  |
|                    | On <b>(Default)</b>    | Turn on/ii the button sound                                    |  |
| Boot Sound         | Off                    | Turn on/ff the operation                                       |  |
| 2001 000110        | On <b>(Default)</b>    | sound when camera is on&off                                    |  |
|                    | Off                    | Turn on/off the date display in                                |  |
| Date Stamp         | On <b>(Default)</b>    | videos   |  |
| Fliping RearCam    | Off( <b>Default)</b>   | Fliping the rearcam's image up&down.lt helps to filp the image |  |
| Image(Up&Down)     | On                     | when installing the external cam in wrong direction            |  |
| Dista NO           | Off(Default)           | Turn on/off displaying the car plat                            |  |
| Plate NO.          | On                     | NO. in the recorded video                                      |  |
| Audio Recording    | Off(Default)           | Turn on/off the audio recording                                |  |
|                    | On                     | when recording video   |  |
| Language           | English(Default)       |  |  |
|                    | Spanish etc            | Select Language for dash cam                                   |  |
| Restore Settings   | Cancel                 |  |  |
| 1 (Cotoro Cottingo | Cofirm                 | Restore All the Settings                                       |  |

#### 7. How to Use WiFi&APPs




Please kindly scan the QR code to view video guidance of using WiFi.

Or search the web address on PC

https://youtu.be/I44bJPuLUFw

#### Step 1. Download APP:

Please Search in Google Play or Apple Store for free APP "Viidure" to download APP





#### Step 2. Turn on the F800's WiFi:

Method 1: Stop Recording Firstly, Long Press on the button.







