


LIGHTSPOT

LIT BELL PUSH | BELEUCHTBAR TASTER | LUMINEUX
BOUTON POUSSOIR | LUMINOSO PULSADOR DE TIMBRE


EN Getting started DE Erste Schritte FR Démarrage NL Aan de slag FI Aloitusopas DK Kom i gang
IT Operazioni preliminari ES Para empezar PT Para começar GR Πρώτα βήματα SE Kom igång

D534WE

1



2



ATTENTION!



—



✓

8V 2A



EN Trouble shooting DE Fehlerbehebung FR Dépannage NL Probleemoplossing FI Vianmääritys
DK Problemløsning IT Risoluzione dei problemi ES Solución de problemas PT Resolução de problemas
GR Αντιμετώπιση προβλημάτων SE Felsökning

livewell.honeywell.com