


TECKNET

Doorbell



The image shows two line drawings of the Tecknet doorbell system. On the left is a square receiver unit with a circular inset in the center containing the word 'TECKNET'. On the right is a round button unit with a bell icon and sound waves inside a circle, with the word 'TECKNET' below it.

User Manual

HWD01878 HWD01888

HWD01878 HWD01888

The diagram shows two sets of hardware components. The left set, labeled HWD01888, includes a square front plate with a circular cutout, a square back plate with a circular cutout, a small rectangular label with a lock icon, a circular battery labeled 'Battery 2032', a rectangular piece of double-sided adhesive tape, and a small rectangular label with a lock icon. The right set, labeled HWD01878, includes a square front plate with a circular cutout, a square back plate with a circular cutout, a small rectangular label with a lock icon, a rectangular user manual labeled 'User Manual', and a small rectangular label with a lock icon. Each component is shown with a corresponding 'x1' quantity indicator.

① Setup Button
② Music Button
③ Volume Adjustment

DE

① Setup-Taste
② Musik-Taste
③ Lautstärke Regelung

EN

EN

EN

DE

DE

DE

FR

FR

FR

ES

ES

ES

IT

IT

IT

