

Ruko[®]

3+
for age



Quick Start Guide


V1.0.2021.08

Carle

If you have any questions about this product, please contact Ruko
by sending a message to Rukobrandstore@gmail.com

www.rukotoy.com

**Please read the instructions before playing and
refer to the user manual for details.**

1 Charging the
robot (about 2h)
Charging Lamp
5V/2A

Not Included

2 Install batteries
for the transmitter


Batteries Not Included



3 Download
and install APP




5 Turn on
transmitter switch



4 Turn on robot switch



6 Connect
Bluetooth (JT_XXXX)



7 Remote
control the robot



Walk or glide backward

8 App control the robot

