

55x65mm 128铜版

Loshall Tag User Manual 2-3 Index 01 Getting Started 02 Add Your Loshall Tag 03 Locate Your Loshall Tag 04 Notifications 05 When Your Loshall Tag Is Lost 06 Resetting Loshall Tag 07 Attentions 08 Extras 09 The Fine Print 10 About Apple Find My Works with Apple Find My	Loshall Tag User Manual 2-3	
	Loshall Tag User Manual 4	
	Loshall Tag User Manual 5	
	Loshall Tag User Manual 6	
	Loshall Tag User Manual 7	

Loshall Tag User Manual 8 05 When Your Loshall Tag Is Lost 05.1 Enabling "Lost Mode": Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your Loshall Tag from the list. Under "Lost Mode" tap "Enable" A screen detailing Lost Mode will pop up. tap "Continue" Enter your phone number or email address and tap "Next". You may enter a message that will be shared with the person that finds your item. Tap "Activate" to enable "Lost Mode" Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled. Note: When "Lost Mode" is enabled, your Loshall Tag is locked and cannot be paired to a new device.	Loshall Tag User Manual 9	
	Loshall Tag User Manual 10	
	Loshall Tag User Manual 11	
	Loshall Tag User Manual 12	
	Loshall Tag User Manual 13	

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.