





| Original                                                                                   | Recharge                                                                                           |
|--------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
|  Power    |  Power            |
|  Tv/AV    |  AV               |
|  1        |  1                |
|  2        |  2                |
|  3        |  3                |
|  4        |  4                |
|  5        |  5                |
|  6        |  6                |
|  7        |  7                |
|  8        |  8                |
|  9       |  9               |
|  0      |  0              |
|  -/--   |  Shift + Guide  |
|  Recall |  Pre Ch         |
|  P.Mode |  Shift + Format |
|  S.Mode |  Shift + Dual   |
|  Nicam  |  Options        |

| Original                                                                                    | Recharge                                                                                    |
|---------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
|  Sleep   |  Sleep   |
|  Edit    |  Smart   |
|  Info    |  Info    |
|  Mute    |  Mute    |
|  Menu    |  Menu    |
|  Still   |  Media   |
|  EPG     |  Guide   |
|  Red     |  Red     |
|  Green   |  Green   |
|  Yellow  |  Yellow  |
|  Blue   |  Blue   |
|  Up    |  Up    |
|  Down  |  Down  |
|  Right |  Right |
|  Left  |  Left  |
|  Enter |  Ok    |
|  CH+   |  Ch +  |



