


Large Wooden Playpen

Instruction Manual

6-24
months



The photos and illustrations shown in this instruction manual are generic.
The manufacturer reserves the right to change any specification or feature without prior notice.

IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.


! WARNING!

This item is not intended to replace adult supervision. Never leave child unattended. Do not place the playpen close to an open fire or other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the playpen. Regularly check the components are tight and secure. Do not leave anything in the playpen which could provide a foothold or create a danger of suffocation or strangulation. Intended for use of children from 6 to 24 months of age or weighing a maximum of 15kg. This package contains small parts and sharp points in an unassembled state. Keep out of reach of children. Do not use the playpen if any part is broken, torn or missing and use only spare parts approved by the manufacturer. Do not use any accessories which are not approved by the manufacturer.

CARE INSTRUCTIONS:

Wipe clean with a soft dry cloth.
For indoor and domestic use only.
Check and tighten all parts regularly.

REFER TO EN12227:2010



KEYCODE: 43141005

MADE IN CHINA

© KMART AUSTRALIA LIMITED

FOR AU / NZ: IMPORTED FOR KMART STORES IN AUSTRALIA AND NEW ZEALAND.

KMART AUSTRALIA - 690 SPRINGVALE ROAD, MULGRAVE, VIC 3170 AUSTRALIA.

KMART NEW ZEALAND - REGIONAL OFFICE C/O KMART PAPATOETOE STORE,
HUNTERS PLAZA, GREAT SOUTH ROAD, PAPATOETOE, AUCKLAND, NEW ZEALAND.

KMART CUSTOMER SERVICE:

AU: 1800 124 125

NZ: 0800 945 995