

Technical Support and E-Warranty Certificate www.vevor.com/support

Electric Mattress Pad

MODEL: HL-TEU-0815

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

Electrical Blanket

VEVOR® TOUGH TOOLS, HALF PRICE







HL-LTE-1316
HL-LTE-1318
HL-LTE-1520
HI -I TF-1820

HL-TEU-8015 HL-TEU-1516 HL-TEU-1619

HLMP-CF-NFI-T HLMP-CF-NFI-P HLMP-CF-NFI-Q HLMP-CF-NFI-K

NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

ENGLISH

Dear customer,

Thank you for choosing a product from our range. Our name stands for high-quality, thoroughly tested products for applications in the areas of heat, weight, blood pressure, body temperature, pulse, gentle therapy, massage, beauty, air and baby.

With kind regards

Contents

1. Items included in the package	4.2 Putting into operation 0
1.1 Description03	
2. Important instructions	
Retain for future use	
3. Intended use 05	
4. Operation 06	8. In the event of problems 0
4.1 Safety	9. Technical data

Product Specifications

Model	HL-TEU-0815
Name	Electric Mattress Pad
Rated Voltage	AC220-240V~50/60Hz
Rated Power	60W
Heating Levels	4Levels
Timer	4 levels of Timer selected 2H,4H,8H,12H. The product will be shut off according to the timer selected.
Controller Model	HL-TEU-S
Product Dimensions	800*1500mm

Explanation of symbols

The following symbols are used on the device, in these instructions for use, on the packaging and on the type plate for the device:

Read the instructions!	30	Wash at a maximum temperature of 30°C, Very gentle wash
Do not insert pins!	×	Do not bleach
	M	Do not dry in a tumble dryer
Do not use folded or rucked!	X	Do not iron

-3	Not to be used by very young children (0-3years)	\boxtimes	Do not dry-clean
20) PAP	Dispose of packaging in an environmentally friendly manner	CE	This product satisfies the requirements of the applicable European and national directives.
	The device has double protective insulation and therefore complies with protection class 2.	A	Please dispose of the device in accordance with EC Directive - WEEE (Waste Electrical and Electronic Equipment).
Ţ	WARNING: Warning of ris	ks of injur	y or health hazards.
Ţ	CAUTION: Safety information about possible damage to appliance/accessories.		
i	NOTE: Important information.		


1. Items included in the package

Check that the exterior of the cardboard delivery packaging is intact and make sure that all contents are present. Before use, ensure that there is no visible damage to the device or accessories and that all packaging material has been removed. If you have any doubts, do not use the device and contact your retailer or the specified Customer Service address.

- 1 Heated underblanket
- 1 Control
- 1 Instructions for use

1.1 Description

- 1.Power plug
- 2. Power cord
- 3.Control
- 4. Timer setting
- 5.0N/OFF button
- 6. Plug-in coupling
- 7. Power ON/OFF button
- 8.POWER Light



2. Important instructions Retain for future use



∕!\ WARNING

- Non-observance of the following notes may result in personal injury or materials damage(electric shock, skin burns, fire). The following safety and hazard information is not intended to protect your health and the health of others, it should also protect the product. For this reason, pay attention to these safety notes and include these instructions when handing over the product to others
- This heated underblanket must not to be used by persons who are not sensitive to heat or by other vulnerable persons who may not be able to react to overheating(e.g. diabetics, people with skin alterations due to illness or scarred tissue in the application area, after taking pain relief medication or alcohol).
- This heated underblanket must not be used by very young children (0-3 years old) as they are unable to respond to overheating.
- This heated underblanket can be used by children older than 3 and younger than 8 years of age provided they are supervised. For this, the control must always be set to the minimum temperature.
- This heated underblanket may be used by children over the age of 8 and by people with reduced physical, sensory or mental skills or a lack of experience or knowledge, provided that they are supervised and have been instructed on how to use the heated underblanket safely, and are fully aware of the consequent risks of use.
- · Children must not play with the heated underblanket.
- · Cleaning and user maintenance must not be performed by children unless supervised.
- This heated underblanket is not designed for use in hospitals.
- This heated underblanket is only intended for domestic/private use, not for commercial use.
- Do not insert needles.
- · Do not use when folded or bunched up.
- · Do not use if wet.
- · Before using it on an adjustable bed, check that the heated underblanket and the cables are not, for example, trapped in a hinge or bunched up.
- This heated underblanket may only be used in conjunction with the control specified on the label.
- This heated underblanket must only be connected to the mains voltage that is specified on the label.

- The electrical and magnetic fields emitted by this heated underblanket may interfere with the function of a pacemaker. However, they are still well below the limits: electrical field strength: max.5000V/m, magnetic field strength: max.80 A/m, magnetic flux density: max. 0.1 millitesla. Please therefore consult your doctor and the manufacturer of your pacemaker before using this heated underblanket.
- Do not pull, twist or make sharp bends in the cables.
- If they are not positioned properly, there may be a risk of becoming entangled in, being strangled by, tipping over, or stepping on the cable and control of the heated underblanket. The user must ensure that excess lengths of cable, and cables in general, are safely routed.
- · Please check this heated underblanket frequently for signs of wear and tear or damage. If any such signs are evident, if the heated underblanket has been used incorrectly or if it no longer heats up, it must be checked by the manufacturer before being switched on again.
- Under no circumstances should you open or repair the heated underblanket (including the accessories) yourself because faultless functionality can no longer be guaranteed thereafter. Failure to observe this will invalidate the warranty.
- · If the mains connection cable of this heated underblanket is damaged, it must be disposed of. If it cannot be removed, the heated underblanket must be disposed of.
- · When this heated underblanket is switched on:
 - Do not place any sharp objects on it
 - Do not place any heat sources, such as hot water bottles, heat pads or similar, on it
- The electronic components in the control warm up when the heated underblanket is in use. For this reason, the control must never be covered or placed on the heated underblanket when it is in use.
- It is essential to observe the information relating to the following chapters: Operation, Cleaning and maintenance, Storage.
- If you should have any questions about using our devices, please contact our Customer Services department.

3. Intended use



!\ CAUTION

This heated underblanket is designed for warming beds, only.

4. Operation

4.1 Safety



- This heated underblanket is equipped with a SAFETY SYSTEM. This sensor technology prevents the
 entire surface of the heated underblanket from overheating by automatically switching off the heated
 underblanket in the event of a fault. If the safety system has switched off the heated underblanket, the
 temperature setting is not illuminated any more even when the heated underblanket is switched on.
- Please note that the heated underblanket is not operable any more due to safety reasons in this case and has to be sent to the service address indicated.
- Do not contact the defective heated underblanket with another control of the same type. This would trigger a permanent switch-off via the control's safety system

4.2 Putting into operation

This heated underblanket must be fixed onto the mattress.

- Leave space for the pillow and place the heated underblanket on the mattress with the plug-in connector facing the pillow. Here, the plug-in connector is located on the underside of the heated underblanket.
- 2. Stretch all of the elastic straps over the corners of the mattress. All 4 corners of the heated underblanket are then fixed onto the mattress.





Regularly check the position of the heated underblanket on the mattress. The heated underblanket must never be used if it is folded.

After you have fixed the heated underblanket to the mattress, simply put your bed sheet on top as usual so that the heated underblanket is between the mattress and the bed sheet.

4.3 How to use



CAUTION

Make sure that the heated underblanket is spread out entirely flat and that it will not rumple up or crease when in use.

SET UP the product

STEP 1:

To operate the heated underblanket connect the control to the heated underblanket by plugging in the connector.





STEP 2:

Then plug in the power plug into the mains outlet.

STEP 2:





WARNINGS:

You must set up the product by correct step by step.

The wrong step of setting up will cause the product be misused and the light "4" will flicker accordingly. Just take off the plug and disconnected the product and operate again the correct way, the product will work again.

Turn on the product

To switch on the heated underblanket, switch the ON/OFF button on the back of the controller.

The POWER light on the screen will be turn on.

Then press the ON/OFF button on the front of the controller.

The POWER light will be normal on during the using time.

Until you switch the back button OFF and then the POWER light will be turn off.

Setting the Temperature

There are totally 4 levels of temperature setting 1-2-3-4.

- 1) press the ON/OFF button on the operator panel, the temperature setting on the 1 level and the timer automatically setting on the 8H.
- Switch the higher/lower temperature level by keeping on pressing the button "+"/ button "-".



Setting the Timer

There are 4 levels of timer setting (2H-4H-8H-12H).

The products will be auto shut off in 2-4-8-12 hours according to your selection.

Switch the timer setting by pressing the button "TIME" and then

switch longer or shorter by pressing the button "+" / button "-".

Turn off the product

- 1) Press the "ON/OFF" button on the operator panel.
- 2) Switch the "ON/OFF" button on the back of the controller, until the POWER light be turned off.



WARNING.

When the timer is up, the light "12H" will flicker to warning you turn off the product.

Just press the ON/OFF button on the top of the controller and switch the back button off, until the POWER light is off to turn off the product.

If you do not switch the back button off, the POWER light will be always on and not safe for using.



NOTE

- The fastest way to warm up the heated underblanket is to initially set the highest temperature setting.
- We strongly recommend switching on the heated underblanket approx. 30 minutes before going to bed and covering it with the guilt to prevent the warmth from escaping.



WARNING

If the heated underblanket is used continuously (for several hours) it is recommended to use the lowest setting of the control to avoid overheating of the user.

5. Cleaning and care



NARNING

Always remove the power plug from the mains outlet and remove the control from the heated underblanket by disconnecting it at the connector. Otherwise there is a risk of electric shock.



CAUTION

The control must never get in contact to water or other liquids. Otherwise the controller may be damaged.

- To clean the controller, use a dry, lint-fee cloth, Do not use any chemical or abrasive cleaning agents.
- The textile cover can be cleaned in accordance with the symbols on the label and must be removed from the controller prior to cleaning.



CAUTION

Note that the heated underblanket must not be dry-cleaned, wrung out, machine dried or ironed.

- The heated underblanket is machine washable.
- Set the washing machine to a particularly gentle, 30 °C cycle (woolens programme). Use a mild detergent with dosage according to the manufacturer's instructions.



CAUTION

Note that the heated underblanket will suffer from too frequent washing. For its entire life, therefore, the heated underblanket should be washed not more than 5 times in a washing machine.

 While the heated underblanket is still damp after washing, shape it to its original form and size and place it flat over a clothes drying rack to dry.



CAUTION

- Do not attach the heated underblanket to washing lines with washing pegs or the like. Otherwise the heated underblanket may be damaged.
- Only reconnect the controller to the heated underblanket after the connector and the heated underblanket are completely dry. Otherwise the heated underblanket maybe damaged.



WARNING

Under no circumstances switch on the heated underblanket to dry it. Other wise there is a risk of an electric shock...

6. Storage

When not in use we recommend to store the heated underblanket in its original packaging. For this purpose, disconnect the control from the heated underblanket by unplugging the plug-in coupling.



CAUTION

- · Allow the heated underblanket to cool down before folding. Otherwise the heated underblanket may be damaged.
- Do not crease the heated underblanket by placing items on top of it during storage.

7. Disposal

For environmental reasons, do not dispose of the device in the household waste at the end of its useful life. Dispose of the unit at a suitable local collection or recycling point. Dispose of the device in accordance with EC Directive-WEEE(Waste Electrical and Electronic Equipment). If you have any questions, please contact the local authorities responsible for waste disposal.



8. In the event of problems

Problem	Cause	Solution
The temperature settings are not illuminated while - the control is properly connected to the heating underblanket - the power plug is connected to a working socket - the slider is set to 1,2,3 or 4	The safety system has switched the heating underblanket off permanently.	Send the heating underblanket and the control for servicing.

9. Technical data

For technical data, see the rating lable on the heated underblanket.











Technical Support and E-Warranty Certificate www.vevor.com/support