




INdbg008V01_GL









D06-078




IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY & INSTRUCTION MANUAL


PARTS

 1 x01	 2 x04	 3 x04
 4 x01	 5 x01	 6 x01
 7 x01	 8 x01	 10 x01
 11 x01		 12 x01

HARDWARE


 A x16	 B x12 +1(spare)	 C x04
 D x08 +1(spare)	 E x01	

01



x2

02



x2

