

Wireless Keyboard For iOS/Android/Windows BTX5050, BK281B



- 1. This keyboard is perfect for smartphone, laptop, desktop, compatible
- with iOS, Android and Windows operation system.
- 2. Please charge the keyboard about 2 hours before using.
- 3. Please read the user manual carefully before you start using this product.
- 4. Function keys feature may have variations depending on the operation system

Indicator Analysis



Pairing Multi-Pairing Bluetooth Keyboard

1.Slide the power switch to "ON", the blue indicator will be on, long press" Fn + 🐧 1" key 3 seconds, the bluetooth keyboard will enter pairing condition while the blue indicator keep flashing at 0.25 second frequency

- 2. Power on the device and select the setting icon on the screen, click it to enter the system preferences list.
- 3. Click the Bluetooth icon to enter the bluetooth device searching condition.
- 4.In the bluetooth device searching list, you can find the "Bluetooth Keyboard",
- 5. After the device connect the bluetooth keyboard successfully, you can start to use the keyboard for typing freely.
- 6.Long press" Fn + **3**2" key 3 seconds,the bluetooth keyboard will enter pairing condition while the blue indicator keep flashing at 0.25 second frequency.
- 7. Follow steps 2-4 to pair additional Bluetooth devices.

Switching Between Devices

Wireless Keyboard can pair up to 2 different Bluetooth devices You will be able to switch between your paired devices by selecting the appropriate assigned Bluetooth key (" Fn + \S 1" or " Fn + \S 2") .

Note: The time between switching devices will take approximately 2-4 seconds.

Low battery reminder

In connected condition, if the blue indicator keep flashing at 0.5 second frequency, please use the charging cable to charge the keyboard till the red indicator off .

If the keyboard is not in use, the keyboard will go into sleep mode after 20 minutes, Simply press any key to wake up the keyboard, It will take 3-5 seconds to reconnect to the device selected

Technical Specifications

Keyboard size: 368x162x(9-20)mm Working distance : ~10m Working voltage: 3.2~4.2V Operation current : <2mA (no backlight) Standby current : <0.5mA (no backlight)

Sleep current : <50uA Sleep time: 20 minutes

Awaken way : click any key to awaken

Functional Key

Key	Fn + on iOS	on iOS	fn+on Android	on Android	fn + on Windows	on Windows
*	Home	Esc	Home	Esc	Browser	Esc
;ò;	Brightness down	F1	Brightness down	F1	Brightness down	F1
. ģ-	Brightness up	F2	Brightness up	F2	Brightness up	F2
AII	Select all	F3	Select all	F3	Select all	F3
G)	Сору	F4	Сору	F4	Сору	F4
	Paste	F5	Paste	F5	Paste	F5
χ,	Cutting	F6	Cutting	F6	Cutting	F6
#	Previous track	F7	Previous track	F7	Previous track	F7
▶II	Play/pause	F8	Play/pause	F8	Play/pause	F8
₩	Next track	F9	Next track	F9	Next track	F9
1	Mute	F10	Mute	F10	Mute	F10
1	Volume down	F11	Volume down	F11	Volume down	F11
◄ >>))	Volume up	F12	Volume up	F12	Volume up	F12
	Screen lock	Del	Screen lock	Del	Screen lock	Del

Press Fn and Q (iOS), W (Android) or E (Windows) keys together to shift between iOS. Android or Windows systems after connected successfully with a corresponding device. Otherwise the keyboard's function key will only be partial valid.

Touchpad Analysis

1.When using Windows systems

Touchpad function	Finger action picture	Finger action	
Move cursor		One finger Slide	
Click once or Click twice		One/Two finger(s) click once or click twice	
Scroll on parallel or vertical	‡ /	Two fingers slide	
Zoom in	To the second	Slide to two sides from center	
Zoom out	S. C.	Slide to center from two sides	
Open the cortana		Three finger click	
Open background window		Three finger slid up	
Show Desktop	My	Three fingers slide down	
Backward	N	Three fingers slide to left	
Forward	N	Three fingers slide to right	

2.When using Android system

Touchpad function	Mouse function	Finger action picture	Finger action
Move	Move the cursor	<u>\</u>	Finger slide
click touchpad once	click touchpad once	V	One finger click
Click right key once	Click right key once	V	Two fingers click

Backlight Control

1. Turn on the backlight:

After the keyboard is connected, press" (*)" key to turn on the backlight.

2. Backlight brightness control: Press "(*) "key once to turn on the first level of backlight by default, press second time to turn on the second level of backlight, press the third time to turn on the third level of backlight, and press the fourth time to turn off the backlight, so as to cycle.

3. Switch the backlight color

After turning on the backlight, press " () " key to switch the backlight color, Available in 7 backlight colors.

Keyboard Maintenance

- 1.Please keep the keyboard away from liquid or humid environment, saunas swimming pool, steam room and don't let the keyboard get wet in the rain
- 2.Please don't expose the keyboard at too high or too low temperature condition.
- 3. Please don't put keyboard under sun for a long time.
- 4. Please don't put keyboard close to the flame, such as cooking stoves, candles or fireplace.
- 5. Avoid shard objects scratching products.

Troubleshooting

Please contact the after-sales service.

It is forbidden to reproduce any part of this quick start guide without the permission of seller

Safety instructions

Do not open or repair this device, do not use the device in a damp environment. Clean the device with a dry cloth.

Warranty

The device is provided with one-year limited hardware warranty from

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

112*160mm 105克铜版纸单色印刷