

PRO HEIGHT ADJUSTABLE SIT STAND DESK RISER

(LARGE)

ELDSKRPLWOA

SAFETY & WARNINGS

WARNING: Use with products heavier than the rated weights indicated may result in instability causing possible injury.




- Read and follow the assembly instructions carefully. Improper installation may result in damage or serious personal injury.
- Retain this user guide for future reference.
- Safety gear and proper tools must be used.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Use the mounting screws provided and **DO NOT OVER TIGHTEN** mounting screws.
- This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

Important: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, contact your place of purchase for a replacement

Maintenance: Check that the product is secure and safe to use at regular intervals (at least every three months).

COMPONENTS



A (x1)



B (x1)



C (x4)



D (x2)




E (x3)




F (x4)

ASSEMBLY


Step 1:



Step 2:




Step 3:




WARNING: Do not press the release handle while cutting off the plastic strip lock. Only press the release handle in an upright position.



Step 4:




Step 5:



Step 6:



Step 7a:



Step 7b:



NOTES

[illegible]

Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com**

kogan.com