

廠商(Supplier)	HiBrite	顏色(Colors)	Front 5 colors, back 5 colors	日期(Date)	2022.1.5
代號(Item No.)	LED2100	特別色(Pantone)	7459c	版本(Version)	S2(change)
品名(Description)	Instruction sheets_A03151	4色(CMYK)	C M Y K	製稿(DRN)	momo
材質(Material)	chrome paper	Cool Gray 11 C→K80		審校(CHD)	
尺寸(Size)	304.8x101.6mm			業務(Sales)	

FOR REFERENCE ONLY
僅供預視用,不能印刷

Manufactured by:
Goods IQ, North Kingstown RI 02852
Under license from The Black and Decker Corporation USA and Canada Only

Black+Decker and the Black+Decker logo are trademarks of The Black+Decker Corporation and are used under license. All rights reserved. Product in this box may differ slightly from that pictured. Not all accessories shown in photography are included in this package.

A03151
Copyright © 2021 Goods IQ

BLACK+DECKER

Verve™ Designer Series
Aluminum LED Lighting

USER GUIDE

Thank You for Choosing Black+Decker!

Save this user guide for future reference.
Please read this user guide before returning this product for any reason.

Table of Contents

Safety Guidelines.....	1-2
Table Lamp Assembly.....	3-4
Clamp Lamp Assembly.....	5-6
Product Features.....	7
How to Use.....	8
Warranty and Contact Information.....	9
Specifications and Contents.....	11

Table Lamp, Wireless

Table Lamp, USB

Clamp Light

Safety Guidelines

It is important for you to read and understand this manual. The information it contains relates to protecting **YOUR SAFETY** and **PREVENTING PROBLEMS**. The symbols below are used to help you recognize this information.

⚠ DANGER: Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury and/or property damage.

⚠ WARNING: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury and/or property damage.

⚠ CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury and/or property damage.

NOTICE: Used without the safety alert symbol indicates potentially hazardous situation which, if not avoided, may result in property damage.

⚠ WARNING: Read all instructions before using appliance.

⚠ WARNING: To reduce the risks associated with impact and hazardous voltage which, if not avoided, could result in death or serious injury and/or property damage:

- Use indoors and in dry locations only; keep all liquids away from the light
- Avoid putting the light on an uneven surface to prevent toppling or damage
- Do not alter or modify the light, or ground plug
- Do not use light with other adapters or voltage supplies
- Do not use the light if the power cord or the enclosure is damaged
- If an extension cord is used, ensure that it is properly rated for your application
- Do not attempt to disassemble light; product is to be serviced by qualified service personnel only—there are no user serviceable parts inside
- Always power off and unplug light before cleaning
- Clean exterior only with a dry, clean cloth; do not immerse light in water to clean
- Do not use force when adjusting light
- Do not insert objects into light
- If any irregularities are detected during use, turn off the switch and unplug the light

⚠ WARNING: To reduce the risks associated with excessive heat and fire which, if not avoided, could result in death or serious injury and/or property damage:

- Avoid usage in high temperature areas (104°F/40°C).
- Avoid putting light next to heater.
- Lights should not be covered with flammable objects (cloth, paper, etc.).

⚠ CAUTION: To reduce the risks associated with environmental contamination which, if not avoided, could result in minor or moderate injury:

- Dispose of task lights in accordance with applicable local government regulations.

⚠ WARNING:

- This device may cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

INTENDED USE: BLACK+DECKER® LED Desk Lamps are intended to provide task lighting indoors. Use in any other application has not been evaluated and may lead to an unsafe condition.

POWER ADAPTER STANDARDS:

SKU	Adapter Standards
Table Lamp, USB	Adapter: 12V, 2A, 24W USB Base Charger (separate power cord): 5V, 1A
Table Lamp, Wireless	Adapter: 12V, 2A, 24W Qi Wireless Charger (separate power cord): 5V, 1A
Clamp Light	Adapter: 12V, 2A, 6W

If you have a question or experience a problem with your Black+Decker purchase, go to [PureOpticsLED.com/Support](#). If you can't find the answer or do not have access to the Internet, call 1-855-784-4322 from 8 a.m. to 5 p.m. Monday – Friday to speak with an agent. Please have the catalog number available when you call. To find the catalog number, please refer to product packaging.

Table Lamp Assembly

FIG. A

FIG. B

FIG. C

FIG. D

1. Attach the lamp head to the forward-angled beam while gently pulling the power cord through the bottom opening. (FIG. A)
2. Using the provided hex key, loosen and remove the screw from the bottom of the beam. (FIG. B)
3. Place the beam into the base and attach using the hex key and screw that was removed in the previous step. (FIG. C)
4. Connect the splitter to the power cord and the base, then connect the splitter to the power adapter cord. (FIG. D)
5. Plug the power adapter into an outlet.

To secure this light to a desk or table, a clamp (Model No. 2100-CLAMP) is available for purchase.

For a full list of contents, see PG. 11

Clamp Light Assembly

Part 1: Clamp Adjustment

The clamp can be secured to vertical surfaces (e.g., cubicle walls) or horizontal surfaces (e.g., shelves) up to 3" thick.

There are two adjustment ranges available:

1. **Factory Preset (1.38" to 3")**
If you wish to use this range, there are no adjustments necessary. Proceed to Part 2: Assembly & Mounting.

2. **Narrow (0.3" to 2")**
If you wish to use this range, follow the steps below.

Narrow Range Adjustment

1. Using the provided hex key, loosen and remove the screws. (FIG. A)
2. Remove the tail stop from the clamp. (FIG. A2)
3. Rotate the pad 180° so that it is upside-down. (FIG. A3)
4. Place the tail stop back into the clamp. (FIG. B4)
5. Reinsert the screws and use the hex key to securely tighten. (FIG. B5)

If you wish to adjust the clamp back to the factory preset range, follow the same steps outlined and turn the tail stop 180°.

FIG. A

FIG. B

Part 2: Assembly & Mounting

1. Using the provided hex key, loosen and remove the screw from the end of the lamp arm. (FIG. C)
2. Put the other side of the clear clip into the arm. Place the into the appropriate clamp opening and attached.
Using the hex key and screw that was removed in the previous step:
• For vertical mounting, see FIG. D
• For horizontal mounting, see FIG. E
3. Slide the clamp onto the mounting surface and twist the knob to tighten. Confirm that the clamp is securely fastened before proceeding to the next step.
• For vertical mounting, see FIG. D
• For horizontal mounting, see FIG. E
4. Connect the power cord to the AC adapter. (FIG. F)
5. Plug the power adapter into an outlet.

FIG. C

FIG. D

FIG. E

FIG. F

Product Features

A. Adjustable Lamp Shade

B. Touch Controls

C. Forward-Angled Beam (Table Lamp Only)

D. Swivel Base

E. Qi Wireless Charging Pad

F. USB 2.0 Charging Port

G. Clamp Mount

How to Use

⚡ Power and Dimming

Tap the button once to power the light on or off. Once the light is turned on, hold down the button to cycle through the brightness levels. **Note:** When powering the light on, it will start up using the last light settings used.

⚙ RGB Color Tuning

This light is equipped with five preset single colors and a gradual color-changing cycle for relaxation. The color-changing cycle also allows you to select any single color to show. To navigate through these modes, simply tap the button once in the following order:

1. Turn on the color-changing cycle.
2. Stop the color-changing cycle on the selected color
3. Turn on "red" preset
4. Turn on "orange" preset
5. Turn on "green" preset
6. Turn on "sky blue" preset
7. Turn on "purple" preset

⚡ Device Charging: Wireless and USB

Table Lamp with Wireless Charging: To use the wireless charging, place your Qi-enabled device on the center of the charging pad. If you are experiencing issues with the charger, follow the troubleshooting steps below:
1. Ensure that all cords and plugs are secure
2. Remove your cell phone case (if applicable) and try to use the charging pad again. Certain phone case styles can interfere with wireless charging.
Table Lamp with USB: To use a USB for charging your device, plug in a USB cord (not included) into the port and plug the other end of the cord into your device.

Warranty and Contact Information

Three-Year Limited Warranty

Goods IQ warrants to the original retail purchaser that the product purchased is free from defects in material and workmanship, and agrees to repair or replace, at Goods IQ's option, any defective BLACK+DECKER® branded desk lamp (3) years from the date of purchase. Warranty is not transferable. Proof of purchase date required. This warranty covers only damage resulting from defects in material or workmanship; it does not cover conditions or malfunctions resulting from normal wear, neglect, abuse, accident, or repairs attempted or made by other than our national repair center or authorized warranty service centers. You are responsible for the costs of shipping the defective product to Goods IQ.

THIS WARRANTY IS THE EXCLUSIVE WARRANTY OF GOODS IQ, AND IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. GOODS IQ SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.


Some states and countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state and country to country. For information on our warranty claim procedure, please contact us at 855-784-4322.

Latin America: This warranty does not apply to products sold in Latin America. For products sold in Latin America, check country specific warranty information contained in the packaging, call the local company, or see the website for warranty information.

Contact Us

To register your new product visit: [PureOpticsLED.com/New-Product](#)
For product support visit: [PureOpticsLED.com/Support](#)
Support contact number: 1-855-784-4322

For troubleshooting and support, scan code or visit [PureOpticsLED.com/Support](#).



Specifications and Contents

Lamp Specifications		Contents		Table Lamp, Wireless and USB	Clamp Light
Watts	5.5 Watts	Desk Lamp	1	1	
Lumens	400 Lumens	AC Adapter	1	1	
CCT Range	3000K 4000K 5000K	Power Splitter	1	-	
CRI	90	Assembly Screw	1	1	
Efficacy	72	Hex Key	1	1	

This device should be installed and operated with a minimum distance of 20cm between the equipment and the user's body.

