




Original	Substituto
 Power	 Power
 Red/ Rec/ I nst ant	 Red
 Green/ <<	 Green
 Yel low St op	 Yel low
 Bl ue/ pl ay	 Bl ue
 Whi te/ >> □	 >>
 >◆	 D. Menu
 [I]	 Gui de
 [o]/ Ti mer	 Sl eep
 [?]	 Ej ect
 [◆]	 For nat
 [≡]/ Text	 Text
 Menu	 Menu
 OK	 Ok
 Up	 Up
 Down	 Down
 Ri ght	 Ri ght

Original	Substituto
 Left	 Left
 Vol +	 Vol +
 Vol -	 Vol -
 Mut e	 Mut e
 P+	 Ch +
 P-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 P<P	 Pre Ch







Original	Substituto
 Power	 Power
 Red/ Rec/ Instant	 Red
 Green/ <<	 Green
 Yellow Stop	 Yellow
 Blue/ Play	 Blue
 White/ >> □	 >>
 [o]/ Timer	 SLEEP
 [?]	 Eject
 [◆]	 Format
 [≡]/ Text	 Text
 Menu	 Menu
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Vol +	 Vol +

Original	Substituto
 Vol -	 Vol -
 Mute	 Mute
 P+	 Ch +
 P-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 P-P	 Pre Ch
 [i +]	 Info
 I - II	 Dual







Original	Substituto	Original	Substituto
 Power	 Power	 Vol -	 Vol -
 Red/ Rec/ Instant	 Red	 Mute	 Mute
 Green/ <<	 Green	 P+	 Ch +
 Yellow Stop	 Yellow	 P-	 Ch -
 Blue/ Play	 Blue	 1	 1
 White/ >> □	 >>	 2	 2
 [o]/Timer	 SLEEP	 3	 3
 [?]	 Eject	 4	 4
 [◆]	 Format	 5	 5
 [≡]/Text	 Text	 6	 6
 Menu	 Menu	 7	 7
 OK	 Ok	 8	 8
 Up	 Up	 9	 9
 Down	 Down	 0	 0
 Right	 Right	 P-P	 Pre Ch
 Left	 Left	 [i+]	 Info
 Vol +	 Vol +	 I-II	 Dual



