



User Manual



True Wireless Earbuds

VEGABUDS

Model NO.: EB1

Thank you for purchasing your new EB1 true wireless earbuds.

We recommend that you spend some time reading this instruction manual in order to fully understand all the operational features it offers.

Read all the safety instructions carefully before use and keep this instruction manual for future reference.

Safety Rules


1. Charge the earbuds and the charging case at least once every 6 months.
2. Do not store the product in extreme temperature (below 0°C or above 45°C)
3. Do not use chemicals or detergents to clean the product.
4. Do not drop or knock the product on hard surfaces.
5. Do not scrape the surface of product with sharp objects.
6. Do not try to take the product apart.

In the Box

Wireless Earbuds
Portable Charging Case
Type-C Charging Cable
User manual
Ear-Tips x 4 (S/L)

-1-

Product Overview



Find Your Fit

1. Choose the size of silicone ear-tips that you feel the most comfortable with.
2. Gently insert the earbuds into ears and adjust to an appropriate angle for comfortable fit.

Tips: Choosing the right ear-tips will give you a better sound quality and noise reduction experience.

L
M
S



-2-

Specification

Bluetooth version	V5.3
BT profiles support	HSP/HFP/A2DP/AVCTP
Bluetooth range	10 m / 33 ft
Frequency response	20 Hz - 20 kHz
Battery capacity	40mAh for each earbuds 300mAh for charging case
Charging time	Around 1.5 hours
Playing time	5-7 hours
Talk time	Around 4 hours
ANC level	-27± 3dB
Speaker Driver	φ10mm
Earbuds weight	4.6g each
Case weight	34g

Power ON/OFF

Power ON

1. Open the charging case, take out the earbuds, they will power on automatically.
2. Long press left and right earbuds for 3 seconds, the earbuds will power on.

-3-

Power OFF

1. Put the earbuds into the charging case, the earbuds will power off automatically.
2. Long press left and right earbuds for 6 seconds, the earbuds will power off.

Remark: Earbuds power off when they stay out of range for over 3 minutes.

Charging

1. Fully charge both the earbuds and the charging case before the first use.
2. To prevent damage, use the provided USB-C cable.
3. Fully dry off the earbuds and the USB port before charging.
4. Charging takes around 1.5 hours.

Earbuds
● Blue LED on
● Blue LED off
● Blue LED Flashing

Charging
 Fully Charged
 Low Battery


Charging Case
● Red LED Flashing
● Red LED on
● White LED Flashing

Charging
 Fully Charged
 Low Battery

-4-

Pairing

1. When using EB1 True Wireless Earbuds the first time. Take the earbuds out of the charging case. One earbud's indicator light will flash white and blue, and the other's will turn off, indicating that pairing mode is on.
2. Turn on Bluetooth on your device.
3. Search and select **EB1**.
4. When connected, the earbuds indicators light off.



-5-

Multi Functions

Function	Left earbud	Right earbud
Play/Pause	Double tap	Double tap
Next song		Triple tap
Previous song	Triple tap	
Volume up		Single tap
Volume down	Single tap	
Answer a call	Single tap	Single tap
End a call	Double tap	Double tap
Reject a call	Long press for 2s	Long press for 2s
Active Siri/ Google Assistant	Tap 4 times	Tap 4 times
ANC on /ANC off /Ambient sound	Long touch for 2s	Long touch for 2s

Factory reset

1. Take out the earbuds from the charging case, ensure both earbuds disconnect with any device.
2. Tap either of the earbuds for 5 times.
3. The two earbuds white LEDs flash 3 times, indicating that the reset is complete.
4. Place both the earbuds inside the charging case and repeat the pairing process.

-6-

WARNING

1. Listening to earbuds at high volume levels, particularly over extended periods of time, may damage your hearing.
2. Supervise children when using equipment. This product is not a toy.
3. The small parts included with this product can be a choking hazard. This product is not intended for use by small children and should be kept away from children under 3 years of age.



-7-