



# KIDS WOODEN KITCHEN PLAYSET

KAWDKTCPLYA



# SAFETY AND WARNINGS

Please retain this information for future reference.



## WARNING:

**CHOKING HAZARD** – Small parts.

- Not for children under 3 years.
- Adults assembly by hand screwdriver required.




### For Safe Use:

- Ensure children are supervised while using the playset.

# COMPONENTS


- Ensure all components have been located and identified before starting assembly.
- If any components appear to be missing, thoroughly check the packaging materials.
- Do not dispose of packaging materials until all components have been located.




# ASSEMBLY

- Assembly to be completed only by an adult.
- Assembly requires use of hand screwdriver (not supplied).



## Step 1:




**Step 2:**



Step 3:




Step 4:







Step 5:




Step 6:




**Step 7:**




Step 8:




Step 9:




**Step 10:**



Step 11:




Step 12:







Step 13:




**Step 14:**




Step 15:




Step 16:




Step 17:




Step 18:




Step 19:



Step 20:




Step 21:







Step 22:




Step 23:




Step 24:




Step 25:




Step 26:



Step 27:



**Step 28:**



**Assembly is complete.**

### **Need more information?**

We hope that this user guide has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com**

**kogan.com**