

旧底图单号	
底图总号	
日期	签名

技术要求

1. 双面彩色印刷
2. 材质为157克进口铜版纸，覆亚膜
3. 幅面尺寸420x285mm，折页后成品尺寸 210x285mm
4. 产品要经设计确认方可量产

					X915 Akuvox快速配置指南	TZ-SM-002171			版本
									V1.0
更改标记	数量	更改单号	签名	日期		等 级	标 记	重 量	比 例
设 计	周豪杰 2020. 12. 24					／	／	／	／
审 核	陈凌谨 2020. 12. 24								
工 艺	赵 欣 2020. 12. 24								
					料号：YS91500000	第 1 张		共 1 张	
标准化	余 芳 2020. 12. 24					福建星网锐捷通讯股份有限公司			
批 准	翁晨曦 2020. 12. 24								

X915X Quick Guide

Installation Environment

Indoor and outdoor installation are supported.
If installing the device outdoors, please do not place device under direct sunlight.
If installing the device indoors, please keep device at least 2 meters away from window and door.

Attention:
Biometric recognition product may not be 100%-accurate and applicable to all scenarios and environment.
For higher security purpose or scenario, please set up access authentication combination.

Installation

Step 1: Wall-mounting Box or Flush-mounting Box Installation

1. Wall-Mounting

1.1 With 86x86 mm embedded junction box in the wall

Fix the wall mounting box on to the embedded box (86) with two M4x30 Screws, mark the positions of the four holes of the wall mounting box at the hole center.

Take off the box and drill the four marked holes using 5 mm drill bit hand drill before inserting the plastic wall anchors into the drilled holes.

Place the wall mounting box closely against the wall while lining up its four holes with their corresponding drilled holes and then fix the wall mounting box on the wall by tightening four ST4 x 20 screws to the plastic wall anchors.

1.2 Without embedded junction box in the wall

According to the position of the wire on the wall, put the wall mounting box closely on to the wall and mark the four positioning holes, while making sure that relative positions between wall-mounting box and wiring holes are correct.

Drill the marked holes using 5 mm drill bit hand drill before inserting plastic wall anchors in to the drilled holes.

Place the wall-mounting box closely against the wall while lining up its four holes with their corresponding drilled holes and then fix the wall-mounting box on the wall by tightening four ST4 x 20 screws to the plastic wall anchors.

Note: It is suggested that you move the bottom edge of the square hole 10 mm away from the wiring hole on the wall as highlighted in green in the drawing.

X915X Quick Guide

2. Flush-Mounting

2.1 Cut out a square hole with the dimension (height * width * depth = 337 * 123 * 43 mm).

2.2 Insert the flush-mounting box in to the hole and mark the positions of the four holes of the flush-mounting box on the wall, then take off the box and drill the holes on the marked positions using 5 mm drill bit hand drill before inserting the plastic anchors in to the drilled holes.

2.3 Break off the round knock-out wiring holes and lead the wires through the corresponding hole in to the flush-mounting box, then press the flush-mounting box in to the square hole. The upper and lower folded edges of the flush-mounting box must fit snugly against the wall. Then fix the box using the four plastic wall anchors and the four ST4x20 screws.

2.4 Make sure that the flush-mounting box are well tightened and its upper and lower folded edges are fit snugly against the wall, fill in the gap between the wall and the flush-mounting box using cement or non-corrosive structural adhesive and wait until the cement is hardened before proceeding to the next step.

STEP 2: Back cover Installation

Hang the one end of the rope on to the square hanger on the wall-mounting/flush-mounting box then hang the other end of the rope on to the square hook on the device for the convenience of the later wire installation etc.

Connect the wires to the terminal blocks as needed (for details, refer to "Device Wiring"), then insert the terminal blocks into the corresponding interface of the main board as indicated in the drawing according to the number of PIN.

Note: The pry bar attached can be used to unplug the terminal blocks if needed.

Choose a suitable size rubber plug (small, large and medium) to hold down the wires, while tearing off the adhesive sticker on the selected rubber plug and stick it on to the X915X back cover and then tear off the adhesive sticker on the other rubber plug of the same size and stick it on to the back cover in the position as indicated in the drawing.

Press the X915X back cover silicone rubber sealing ring in to the corresponding groove as indicated by the arrow and then tighten the back cover using the six M3x4 screws to its corresponding holes.

STEP 3: Device Mounting

Take off the rope and hang the device on to the two square hangers on the wall-mounting/flush-mounting box. Stick the plate removal key in to the small hole on the upper left corner of the card reader touch plate to pull out the plate.

Drive the two Torx screws in to their corresponding holes.

Press the card reader touch plate in to the card reader opening.

Installation is completed.

Akuvox Smart Intercom

X915X Quick Guide

Device Wiring

Application Network Topology

Configuration

- 1.IP address Checking:** Press 9999 on the dial screen, then press 3888 to enter the system screen and click Info to check the device IP address. X915 uses DHCP by default.
- 2.Account Registration:** On the web interface, go to the path Account -> Basic page to register and fill in the account information. (please refer to user manual for more information)

Operation

Make a call:
Enter the IP or SIP number and press Dial tab to make a call.

Receive a call:
X915 supports Auto Answer by default. Incoming call from indoor device will be answered automatically.

Unlock by PIN:
Enter the PIN code on the home screen for the door access.

Unlock by RF Card:
Place the configured RF card on the RF card reader area for the door access.

Notice Information

Information contained in this document is believed to be accurate and reliable at the time of printing. This document is subject to change without notice, any update to this document can be viewed on Akuvox's website: <http://www.akuvox.com>. © Copyright 2020 Akuvox Ltd. All rights reserved.

AKUVOX (XIAMEN) NETWORKS CO., LTD.
ADD: 10/F, NO.56 GUANRI ROAD, SOFTWARE PARK II, XIAMEN 361009, CHINA
www.akuvox.com

Akuvox Smart Intercom

X915X Quick Guide

Unpacking

Before you being using the device, please check the version you obtained and ensure that the following items are included in the shipped box:

Mainframe Accessories:

Flush-mounting Accessories (Please find in In-Wall Installation Kit box):

Wall-mounting Accessories (Please find in On-Wall Installation Kit box):

Product Overview

X915X