



Rotate the knob to unlocked position.

Step 1




1. Long press the reset button with a reset tool;
2. Take out one battery.

Step 2



Re-install the battery while holding the reset button.

Step 3



Keep holding the reset button until you hear the sound of "BEEP".

Step 4

