

product name	Lollipop karaoke microphone
Model	K02
Bluetooth version	V5.0
power	3W
weight	About 240g
Product size	92*92*188mm
Appearance material	Sponge+ABS
Battery capacity	1200mah
Charging specifications	DV0.5A

Pairing with digital devices

1. Press and hold the play/pause button to turn on the speaker, the blue light flashes, and the speaker enters a connected state.
2. Open Bluetooth on the digital device, search for 'K02', and click on 'Connect'.
3. The speaker will make a "dong" sound, indicating successful connection, and the blue light will remain on. If the device is not connected, the blue light will flash slowly.
4. After successful pairing, short press the play button to play and pause music.

Charging:


The charging process prompt light is always red, but it turns off when fully charged. When the battery is low, the red light flashes quickly, and a low battery prompt sound will be broadcast. It will prompt 3 times, and the fourth time it will shut down.

*Please use a DC-5V charger/adaptor for charging. Improper chargers may cause hardware damage and other malfunctions.

Precautions:

1. Regarding the usage environment of Bluetooth: Wireless signal transmission, including Bluetooth, is greatly affected by the surrounding environment, such as metals, trees, human bodies, and obstacles that can absorb signals to a certain extent. Thus, the distance transmitted in practical applications will have a certain impact.
2. It is prohibited to charge the battery under fire and hot conditions! Do not use this product near heat sources such as fire or heaters. Do not expose the host to several hot environments, such as direct sunlight or in the car on hot days. Otherwise, it will reduce the performance of the battery or shorten its service life.
3. When not in use for a long time, please charge the battery at least 50% of its charge before storing it safely.
4. Products should be stored in an indoor warehouse with a temperature of 25 degrees Celsius and a humidity of no more than 75% to minimize the capacity degradation of the battery cells.
5. During transportation, products should be protected from rain and water immersion to prevent long-term storage in high-temperature environments.

Lollipop karaoke microphone User manual



The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:


- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



On/Off key: Press and hold for 3 seconds to turn on/off.
Short press the magic sound switch: Goddess mode>Male god mode>Baby sound>Magic sound mode>Original sound.
Double click: Turn microphone pairing on/off.
Three strikes: Switch microphone playback mode (Bluetooth/LIN mode).
Key addition: Short press the previous song, long press the speaker volume, and double-click to cancel the original sound.
Minus key: Short press one song, long press the speaker volume, double click to turn off the microphone, and then double click to turn on the microphone.
Note: The speaker volume and microphone volume are set to the maximum by default when turned on.
5V charging/AUX: Line in function can be connected to the phone to record songs. Headphone interface: used to connect 3.5mm headphones.
Note: Horn volume increase or decrease is invalid in LIN IN mode.