



Dual Battery Charger

GXCH2LPE19
for Canon
LP-E19, LP-E4, and LP-E4N Batteries
Manual


Thank You for Choosing Green Extreme

Thanks for choosing Green Extreme products. For optimum performance and safety, please read these instructions carefully before operating the product. Please keep this manual for future reference.


















Safety Warnings

- Do not charge any battery other than Canon LP-E19 and LP-E4/E4N rechargeable batteries. Other types of batteries can burst, causing personal injury and damage.
- Do not disassemble the charger. Take the charger to a qualified service technician when service or repair is required. Improper use may result in the risk of electric shock or fire.
- Do not operate the charger if it has received a sharp blow or has been dropped or damaged in any way.
- Never expose the charger to rain or moisture.
- Do not use an extension cord when using the charger. This can result in fire or electric shock.
- Never use the charger as a DC power source for any electrical equipment.
- Always unplug the charger from the AC outlet before handling the batteries.
- Unplug the charger from the AC outlet before cleaning.

Overview



LED Status Indicators

 LEDs 				
Charge Status LEDs	  	  	  	  
Charge State	<50%	50% to 80%	80% to 100%	100%

Note: If the charger detects defective batteries, the charge status LEDs will flash with an irregular pattern.



Flashing (Charging)



Solid (Charged)



Off


Features

- Sequential charging for two Canon LP-E19 or LP-E4/4N rechargeable batteries.
- LED indicators display when batteries are charging and when they're ready to use.
- Overheating detection minimizes possible high temperatures and automatically shuts off the charger.
- Short-circuit protection prevents the charger and batteries from receiving excessive amounts of current.
- Surge-protection circuits guard the charger from overcurrent or defective and shorted batteries.
- The universal 100~240V AC input is perfect for travelling and charging anywhere.

Note: It is normal for the batteries to become warm during charging. This unit sequentially charges the batteries in the order they are inserted.

Specification

Input Power	100~240V AC, 50/60Hz
Charging Current	980mA \pm 50mA
Output	12.6V DC
Operating Temperature	32°F to 104°F (0°C to 40°C)
Dimensions (H x W x D)	2.4 x 6.3 x 3.7 in. (60.9 x 160 x 95 mm)
Weight	10.5oz. (297g)
Certifications	CE



One Year Green Extreme Limited Warranty

GREEN EXTREME warrants to the original purchaser that your GREEN EXTREME product shall be free from defects in material and workmanship for the period of one (1) year from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later.

GREEN EXTREME's entire liability and your exclusive remedy for any breach of warranty shall be, at GREEN EXTREME's option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as GREEN EXTREME may direct with a copy of the sales receipt or dated itemized receipt. GREEN EXTREME may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts are in compliance with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period of time that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by GREEN EXTREME, except where such restriction is prohibited by applicable law.

Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws.

To start a warranty claim contact the GREEN EXTREME Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to GREEN EXTREME, along with the RMA number and proof of purchase.

Question about our product line? Need Product Support?

We are proud of our products and celebrate our customers.

We are with you, from product selection to everyday use.

Be secure with your purchase and reach us as you need.

☎ 212-647-9300

✉ brands@adorama.com

📍 Adorama Brands,
42 West 18th Street,
New York, NY 10011

You can always contact us at BRANDS@ADORAMA.COM for personal technical support. Our website contains a wide range of Support and FAQ pages with valuable technical assistance.

Green Extreme is a registered trademark of ADORAMA CAMERA.

© 2021 Adorama Camera, Corp.

All Rights Reserved.