



Original	Substituto
	Power
	Auto Off
	Sleep
	Muting
	1
	2
	3
	Disc
	4
	5
	6
	+10
	7
	8
	9
	0
	Program
	Shift + Power
	Shift + Sleep / Timer
	Mute / Dimmer
	1
	2
	3
	Display / Media
	4
	5
	6
	Guide / EPG / - / - -
	7
	8
	9
	0
	TV/ Radio /

Original	Substituto
	Cancel
	Repeat
	Random
	Tape
	CD
	Tuner
	AUX
	EQ
	3D AI
	<< / Tune-
	Left / Preset-
	>> / Preset+
	>> / Tune+
	S. Woofer
	Left
	Down
	CH- / Page-
	Exit / Cancel / Clear
	Green / APP / Repeat
	Blue / Prime Video / Random
	Shift + 5
	Shift + 3
	Shift + 6
	Shift + 7
	Subtitle / EQ
	Smart / List
	<< / Tune-
	Left / Preset-
	>> / Preset+
	>> / Tune+
	Sound / Title
	Left
	Down
	CH- / Page-



