

## **SIMOLIO Long Cord Headphones for TV, Cord Detachable Model: SM-905TV**

### **Q: Do these headphones need a battery to work?**

Yes. **Charge and power on** the headphones before hooking up the headphones to your device.

### **Q: Can this headphones be used wirelessly?**

No, it must be used with cable. These are **NO** Bluetooth wireless headphones.

### **Q: No sound from headphones after hook up?**

Step 1: Make sure headphones are **charged** on **turned on**(**green LED on**).

Step 2: If you are using the RCA converter together with the long cable, make sure the red and white ports connected are marked “**OUTPUT**” or “**AUDIO OUT**”.

Step 2: Go to the sound menu settings on your TV and set TV audio settings to “Headset” or “External Speakers” (Samsung TV). Check your TV user manual for step-to-step guidance on how to set TV properly, or contact seller/manufacturer with TV brand and models.

### **Q: Will TV Speaker be muted if headphone is plugged into TV?**

This actually depends on your TV models and brands. On some TV models, the TV’s speakers will be either automatically muted when you plug something into an audio out port (AUX/RCA, etc.) or they become disabled once you choose “External Speakers” as your TV’s audio output.

### **Q: My TV only has a SPDIF/DIGITAL OPTICAL/TOSLINK port. Will these headphones work with my TV?**

No, but there are various solutions to this.

Option 1: purchase a digital to analogue converter (not included in the packaging).

Option 2: if you have a TV box/amplifier connected to your TV, connect headphones to your TV box or amplifier.

Option 3: Go check Simolio wireless tv headphones series. Wired headphones on the market generally support RCA/3.5mm connection **ONLY**.

**Q: Where I can find the tone control that the product description mentions?**

The tone control is built in the right earphone. Just open the battery cover on the right earphone. Rotate the switch to right for getting audio with clarity.

**Q: I have VIZIO TV. Very bad sound quality from headphones after hook up?  
Frequent audio dropouts?**

Use your TV remote control and set as follows: **Menu>Audio>Analog Audio  
Out>Fixed.**

**Q: Can I use these for calls on my laptop?**

Sure. Just remember to use the 1.5-meter long audio cable with in-line MIC when answering calls or on-line chats.

**Q: How long will the battery run per charge?**

About 40 hours. Depending on headphones volume levels, play time could be shorter or longer.

**Q: Is battery replaceable?**

Yes. Battery is replaceable and replacement battery can be purchased from Simolio store on Amazon.