



TIMED WATERING:

Turn dial clockwise and align the desired number of minutes with the **TIME INDICATOR**. To turn off before time runs out, rotate the dial back to "0" and push up on the release lever to turn off.

MANUAL (NON TIMED) WATERING:

Depress the **RELEASE LEVER** and rotate dial counter clockwise to "Manual On". Water will stay on unless you turn it off. Rotate back to "0" and push up on release lever to turn water off.

RIEGO CON TEMPORIZADOR:

Gire el selector en dirección de las manecillas del reloj y alinee el número deseado de minutos con el **INDICADOR DE TIEMPO**. Antes de que se termine el tiempo, gire el selector a "0" y presione la palanca de liberación para apagarlo.

RIEGO MANUAL

(SIN TEMPORIZADOR):

Baje la **PALANCA DE LIBERACIÓN** y gire el selector en dirección contraria a las manecillas del reloj a la posición "Manual On". El sistema de riego permanecerá encendido a menos que lo apague. Gire el selector a "0" y presione la palanca de liberación para apagarlo.

