



COOL FANS™ SOUND VIBEZ INSTRUCTION MANUAL

Cool Fans™ Sound VibeZ is not a toy. Unlike some other Bluetooth® hands free devices, Cool Fans™ Sound VibeZ doesn't come with a microphone for voice conversation. Never try to use it for that purpose.

To prevent damage or harm to those using this product and surrounding, please read all safety warnings before use.

PRODUCT SPECIFICATIONS

- Operating Time (approximately):

	Low speed	Medium speed	High speed
Fans only	5 hours	3.5 hours	2 hours
Bluetooth & Fans	4 hours	2.5 hours	1.5 hours

- Battery: Built in Li-ion rechargeable batteries 3.7V 2600mAh 9.62Wh (non-replaceable)
- Input Power: DC 5V 1A (USB charging)
- Charging Time (approximately): 8 hours
- Accessory: USB charging cable

CHARGING COOL FANS™ SOUND VIBEZ

Use the provided USB cable to connect Cool Fans™ Sound VibeZ to a power source such as AC USB adapter, portable charger or computer USB port. A red light will appear while Cool Fans™ Sound VibeZ is charging. Remove the cable once the light turns off and it is fully charged. Never overcharge the Cool Fans™ Sound VibeZ battery.

The red light will flash when the battery is running low and the battery needs to be charged.

USING COOL FANS™ SOUND VIBEZ

Place Cool Fans™ Sound VibeZ around your neck and turn it on. Turn off the fan before removing.



POWER ON

Press and hold the POWER button for 3 seconds. Power on sound and "Pairing" voice is heard. Blue light near the power button will begin to flash.

BLUETOOTH® SPEAKER PAIRING

Make sure the device such as smart phone, tablet or computer you are using with Cool Fans™ Sound VibeZ has Bluetooth® capability and its Bluetooth® function is turned on.

Once Cool Fans™ Sound VibeZ is turned on, it enters pairing mode and the blue light flashes.

Look for "Cool Fans" on the Bluetooth® device list and click connect. When Bluetooth® speaker is connected successfully, the voice "Connected" is heard and the blue light will change from flashing to a steady non-flashing light.

BLUETOOTH® SPEAKER AUTO CONNECT & DISCOVERABLE

If there is a device previously paired with the fan and its Bluetooth® connectivity is turned on, the fan will try to connect to the device automatically.

If the previously paired device is not found after 10 seconds, the light will flash red and blue alternatively. The fan will become discoverable for other Bluetooth® device to pair.

If Cool Fans™ Sound VibeZ does not pair with a device after it has been turned on for 1 minute, the fan will exit pairing mode and turn off the Bluetooth® function as well as the red and blue lights. A notification sound will be played to notify you.

If you want to enable Bluetooth® function again, you will need to power off the Cool Fans™ Sound VibeZ and turn the power back on to enable the Bluetooth® connectivity.

DISABLE CURRENT PAIRING & PAIR WITH A NEW DEVICE








To disconnect Cool Fans™ Sound VibeZ from a paired device and pair it with another device, power off Cool Fans™ Sound VibeZ then press and hold the POWER button for 5 seconds until the alternating red and blue flashing light is seen. To connect the fan to the new device, repeat the steps mentioned in BLUETOOTH® speaker PAIRING.

USING COOL FANS™ SOUND VIBEZ

DISCONNECT BLUETOOTH® SPEAKER PAIRING

Turn off Bluetooth® function on your device to disconnect with Cool Fans™ Sound VibeZ. The “Disconnected” voice is heard.

LIGHT INDICATION

Status	Blue Light	Red Light
Bluetooth Pairing Mode		
Device Connected		
Bluetooth Pairing Mode (Discoverable for all device)	  (Flash alternatively)	
Low Battery		
Charging Battery		
Battery fully charged		

FAN SPEED

Cool Fans™ Sound VibeZ has 3 fan speed levels which are Low, Medium and High. When the unit is turned on, toggle between different fan speed and turn off the fans by quickly pressing and releasing the FANS button.

LIGHT MODES

Cool Fans™ Sound VibeZ has 3 light modes to choose from. When the unit is turned on, quickly press and release the POWER button to select between steady white lights, color changing lights and lights off.

POWER OFF

Press and hold the POWER button for 3 seconds to turn off Bluetooth® connection, fans & light at the same time.

When there is no Bluetooth® connection and the fans and lights are both turned off, the Cool Fans™ Sound VibeZ will auto turn off after 30 seconds to save power.

DESK FAN SETUP

To use Cool Fans™ Sound VibeZ as a desk fan, place the fan with the POWER button facing upward on any flat surface and angle the fan arms as desired.

BANZAI IS USED UNDER LICENSE BY FOCUS BRAND LTD.
CONTENTS AND SPECIFICATIONS MAY VARY FROM THOSE ILLUSTRATED.



04250
TANG RONG ROAD,
CHANGPING, DONGGUAN, CHINA
ALL RIGHTS RESERVED
MADE IN CHINA

SAFETY PRECAUTIONS

When wearing or using Cool Fans™ Sound VibeZ, always follow all safety precautions.

WARNING: There is risk of serious injury if Cool Fans™ Sound VibeZ is misused

- If Cool Fans™ Sound VibeZ becomes overheated and begins to smoke, turn off the product immediately and discontinue use. If this occurs while charging, disconnect the power source and charging cable at once.
- Do not place small objects in the fan cages, as this may cause damage or a malfunction. Always keep fingers or hair away from fan cages. Immediately turn off Cool Fans™ Sound VibeZ if hair becomes entangled in the fan blades.
- Keep personal belongings away with fan blades.
- Cool Fans™ Sound VibeZ is not waterproof; don't use in rain or in a pool. If Cool Fans™ Sound VibeZ becomes wet, then immediately turn it off and set aside until completely dry.
- Moisture from sweating may cause damage to the USB charging port. To prevent damage wipe off any moisture on the product as a result of sweat.
- Don't over bend or rotate the fan arms beyond 180°, as this may damage the product.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Banzai International Ltd is under license. Other trademarks and trade names are those of their respective owners.