




SPECIFICATIONS

Model Number:	WG9
Connectivity:	2.4GHz
Switch Lifetime:	5 Million Clicks
Sensor:	Pixart Optical Sensor
Speed (Max):	30 IPS
Acceleration (Max):	10 G
Polling Rate:	500 Hz
Battery Capacity:	600 mAh
Battery Lifetime:	± 85 Hours
Size:	123*67*44 mm
Weight:	94 ± 1 g
Power Rating:	3.7V $\approx$ 15 mA
Compatibility:	Windows® 7 or later & Mac® OS 10.11 or later.

PRODUCT TOUR



EN

- A** USB C Port
- B** Left Mouse Button
- C** Right Mouse Button
- D** Scroll wheel
- E** DPI Button
- F** Forward Button
- G** Back Button
- H** Mouse Feet
- I** Power ON/OFF Switch
- J** USB Receiver
- K** Optical Sensor

ID

- A** Port USB C
- B** Tombol Kiri Mouse
- C** Tombol Kanan Mouse
- D** Roda Gulir
- E** Tombol DPI
- F** Tombol Maju
- G** Tombol Kembali
- H** Alas Mouse
- I** Tombol ON/OFF
- J** Penerima USB
- K** Sensor Optik

ZH

- A** USB C 连接口
- B** 鼠标左键
- C** 鼠标右键
- D** 滚轮
- E** DPI 按键
- F** 前进键
- G** 后退键
- H** 鼠标脚垫
- I** 电源开关键
- J** USB 接收器
- K** 光学传感器

ES

- A** Puerto USB C
- B** Botón izq. del ratón
- C** Botón der. del ratón
- D** Rueda de desplazamiento
- E** Botón DPI
- F** Botón de avance
- G** Botón de retroceso
- H** Pies de ratón
- I** Interruptor de encendido/apagado
- J** Receptor USB
- K** Sensor óptico

JP


- A** USB Cポート
- B** マウスの左ボタン
- C** マウスの右ボタン
- D** スクロールホイール
- E** DPIボタン
- F** 進むボタン
- G** 戻るボタン
- H** マウスパッド
- I** 電源オン/オフスイッチ
- J** USBレシーバー
- K** 光学センサー

KR

- A** USB C 포트
- B** 마우스 왼쪽 버튼
- C** 마우스 오른쪽 버튼
- D** 스크롤휠
- E** DPI 버튼
- F** 앞으로 단추
- G** 뒤로 버튼
- H** 마우스 패드
- I** 전원 켜기/끄기 스위치
- J** USB 수신기
- K** 광학 센서

Join the Fantech
Discord
Community





ANY QUESTIONS?

Wondering how to use your new epic Fantech gaming gear, or have any other questions? Reach out to our dedicated support team.

support@fantechworld.com

WG9
KANATA WIRELESS
GAMING MOUSE



QUICK START GUIDE

PANDUAN CEPAT [ID]
快速入门指南 [ZH]



STEP 1: DOWNLOAD


To further customize your settings, please visit our website and download the software (if applicable).



www.fantechworld.com

STEP 2: HOW TO CONNECT

USB C CHARGING CABLE



*The USB C charging cable is exclusively for charging; this mouse does not support a wired mode.



2.4GHZ CONNECTION



1



2



*You have the option to choose between ECO mode and ON mode for using the mouse. ECO mode operates without lighting, whereas ON mode activates the lighting.



DPI INDICATOR

Red	800	
Blue	1200	
Green	2000	